

EtherLINQ

**4G/LTE Ethernet Router
with WiFi, VPN & Firewall**

User's Guide

Version 5.2



CONTENTS

CONTENTS	II
ABOUT THIS USER'S GUIDE	VI
SAFETY WARNINGS	VII
CHAPTER 1: INTRODUCTION	1
1.1 Key Features	1
1.2 Package Contents	2
CHAPTER 2: HARDWARE	3
2.1 Front LEDs	3
2.2 Rear Panel	4
2.3 Hardware Setup	5
CHAPTER 3: ACCESSING THE ETHERLINQ	6
3.1 Start-up and Login	6
3.2 Navigating the User Interface	7
3.3 Top Level Menu Structure	8
CHAPTER 4: QUICK SETUP	10
4.1 Quick Setup	10
4.2 Password	11
4.3 LAN Configuration	12
4.4 WiFi Configuration	12
4.5 Accessing Remote Devices	13
CHAPTER 5: STATUS TAB	14
5.1 Device Status	14
5.2 Modem Signal Quality Graph	16
CHAPTER 6: MODE TAB	18
6.1 NAT Router Mode	19
6.2 IP Pass-Through (Bridge) Mode	23
6.3 Virtual Cable Mode	24
CHAPTER 7: LTE TAB	27

7.1	LTE Setup.....	27
7.2	LTE Keep-Alive.....	27
CHAPTER 8:	WAN TAB	29
8.1	WAN Setup.....	29
8.2	WAN Fail-Over	30
8.3	WAN Keep-Alive.....	30
CHAPTER 9:	WIFI TAB	32
CHAPTER 10:	VPN TAB	34
10.1	IPSec VPN Settings	35
10.2	Add an IPSec Net-to-Net Rule	36
10.3	Add an IPSec Remote User Rule.....	39
10.4	IPSec Tunnel Status.....	42
CHAPTER 11:	GPS TAB.....	44
11.1	GPS Setup	44
11.2	GPS Data Streams.....	45
CHAPTER 12:	USB TAB.....	46
12.1	USB Webcam Setup	46
12.2	USB Serial Device Server Setup.....	49
CHAPTER 13:	ADVANCED TAB	50
13.1	Device Access	50
13.2	Scheduled Reboot.....	51
13.3	Dynamic DNS (DDNS)	52
13.4	Syslog Server	53
13.5	Additional Configuration	54
CHAPTER 14:	ADMIN TAB	55
14.1	Device Maintenance.....	55
14.2	Configuration Settings.....	57
14.3	Tools	58
14.4	Debug Information.....	59
CHAPTER 15:	LOG TAB	60
CHAPTER 16:	CONFIGURATION MODE	61
APPENDIX	62

A.1	Common Tasks.....	62
A.2	Troubleshooting.....	63
A.3	Common Carrier Specific Issues.....	64
A.4	Accessing Remote Devices	65
A.5	Cellular Signal Issues.....	67
A.6	Updating EtherLINQ Firmware.....	68
A.7	Specifications	72
A.8	EtherLINQ Default Settings.....	75
A.9	Legal Information.....	76
A.10	FCC Certification	77
A.11	Safety and Hazards.....	79
A.12	Proxicast Limited Warranty	80
A.13	Customer Support	81
INDEX		82

Document Revision History

June 3, 2019	Version 5.2:	Updated for firmware v5.2.x new/revised features
July 25, 2018	Version 5.1:	Initial release

Related Documents & Resources

EtherLINQ Quick Start Guide

<http://www.proxycast.com/support/files/EtherLINQ-3-QuickStartGuide.pdf>

EtherLINQ Technical Support (Documentation, Firmware Updates, KnowledgeBase)

<https://support.proxycast.com>

EtherLINQ Accessories

<https://shop.proxycast.com>

About This User's Guide

Intended Audience

This manual is intended for users who need to configure the EtherLINQ using the device's embedded web interface. You should have at least a basic knowledge of TCP/IP networking concepts and topology.

Related Documentation

- **Quick Start Guide**

The Quick Start Guide is designed to help you get up and running right away. It contains information on setting up your network and configuring for Internet access.

- **Firmware Release Notes**

Every EtherLINQ firmware release includes a description of the new features and improvements.

- **Proxicast Support Web Site**

Please refer to <https://support.proxicast.com> for additional support documentation and access to our Knowledgebase.

Syntax Conventions

- The EtherLINQ may be referred to as the "EtherLINQ", the "device", the "router", or the "system".
- The EtherLINQ's wired Ethernet WAN interface may be referred to as "WAN", "Wired WAN" "Ethernet WAN", "WAN (Ethernet)" or "WAN 1".
- Product labels, screen names, field labels and field choices are all in **bold** font.
- A key stroke is denoted by square brackets and uppercase text, for example, [ENTER] means the "enter" or "return" key on your keyboard.
- "Enter" means for you to type one or more characters and then press the [ENTER] key. "Select" or "choose" means for you to use one of the predefined choices.
- The example screens shown in the User's Guide may differ slightly from the actual screens on the EtherLINQ, depending on the firmware version the EtherLINQ is running.

Safety Warnings

- Do NOT use this product near water.
- Do NOT expose your device to dampness, dust or corrosive liquids.
- Do NOT store things on the device.
- Do NOT install, use, or service this device during a thunderstorm.
- Connect ONLY suitable accessories to the device.
- Do NOT open the device or unit. Opening or removing covers can expose you to dangerous high voltage points or other risks. ONLY qualified service personnel should service or disassemble this device. Please contact your vendor for further information.
- Make sure to connect the cables to the correct ports.
- Place connecting cables carefully so that no one will step on them or stumble over them.
- Use ONLY an appropriate power adapter or cord for your device.
- Connect the power adapter or cord to the right supply voltage (for example, 110V AC in North America or 230V AC in Europe).
- Do NOT allow anything to rest on the power adapter or cord and do NOT place the product where anyone can walk on the power adapter or cord.
- Do NOT use the device if the power adapter or cord is damaged as it might cause electrocution.
- Do not use the device outside, and make sure all the connections are indoors. There is a remote risk of electric shock from lightning.
- Do NOT obstruct the device ventilation slots, as insufficient airflow may harm your device.
- Antenna Warning! This device meets ETSI and FCC certification requirements when using the included antenna(s).
- If you wall mount your device, make sure that no electrical lines, gas or water pipes will be damaged.

This product is recyclable. Dispose of it properly.



CHAPTER 1: INTRODUCTION

The EtherLINQ is Proxicast's fourth generation of enterprise-grade secure cellular gateways. This series features an embedded LTE cellular modem. The internal modem seamlessly becomes a WAN interface for the EtherLINQ's router and is fully integrated with all of the EtherLINQ's security, performance, and management capabilities.

As with its predecessors, the EtherLINQ is loaded with security features including VPN, firewall and access control. The EtherLINQ adds improved throughput and reliability, NAT, port forwarding, DHCP server, an integrated USB Webcam server, serial device server, GPS functionality (in some models) and many other powerful features required for complex and demanding applications.

The EtherLINQ also has a built-in IEEE 802.11 b/g/n WiFi radio that functions as an access point. This allows WiFi devices to securely communicate with the EtherLINQ and access the wired network or Internet.

The EtherLINQ's all metal construction make it the perfect choice for applications where a high-performance, secure, reliable and rugged cellular router is required.

1.1 Key Features

1. WAN Failover

Proxicast's EtherLINQ supports failover between fixed-line Ethernet (e.g. xDSL/cable modem) WANs and its internal LTE modem offering non-stop network connectivity. Users can define which WAN interface has priority and the parameters for failover and fall-back actions.

2. IPSec Server & Client

The EtherLINQ's embedded IPSec VPN features allow remote users to make secure connections to devices which normally cannot run VPN software. The EtherLINQ can also establish site-to-site IPSec tunnels to existing corporate VPN servers for enterprise-level data security.

3. NAT-Router, IP Pass-Through (Bridge) and Virtual Cable Mode Operations

The EtherLINQ can be configured as a traditional NAT router serving as a LAN gateway device. Optionally, it can be configured as a Bridge to provide direct Internet connectivity to a single device (Ethernet or WiFi). The EtherLINQ also supports Proxicast's unique "Virtual Cable Mode" operation – a special virtual private networking technology that tunnels through any intervening network topologies to make devices connected to the EtherLINQ appear as if they are wired directly to devices connected to a remote EtherLINQ (or PocketPORT).

4. WiFi Access Point

The EtherLINQ includes an 802.11 b/g/n compliant access point bridged to its LAN so that both wired and wireless devices can share the EtherLINQ's WAN connection.

5. USB Webcam & Serial Device Servers

The EtherLINQ includes 2 application servers – one for USB web cameras and one for USB serial devices. Basic video capabilities can be easily added to remote installation; with an RS-232/422 to USB adapter, legacy serial devices can also be accessed.

6. GPS Server

Certain EtherLINQ models include GPS functionality to both serve and push NMEA data streams to geolocation-enabled applications.

7. Dynamic Feature Control

Administrators can enable / disable various EtherLINQ features as necessary for additional security.

8. Industrial Design

Designed specifically for industrial and mobile applications, the EtherLINQ's rugged steel chassis and Kensington Lock slot provide physical security along with conveniences such as a locking power supply and removable screw-down mounting tabs.

9. Energy Efficient

The EtherLINQ's low power consumption SOC chip makes it ideal for solar or battery-powered installations, consuming less than 3 W under normal operating conditions.

1.2 Package Contents

- 1x EtherLINQ
- 1x 120/240 VAC to 12 VDC Locking Power Adapter
- 2x 5 dBi LTE Antennas (Flat)
- 2x 5 dBi WiFi Antennas (Round)
- 1x SIM Adapter Kit
- 1x 8 GB microSD Card (installed)
- 1x CAT5e Cable
- 4x Rubber Feet
- 1x Mounting Hardware Kit
- 1x Quick Start Guide

CHAPTER 2: HARDWARE

2.1 Front LEDs



Figure 1: EtherLINQ Front Panel

LABEL	LED STATE	DESCRIPTION
MicroSD		Slot for microSD cards. Must be formatted for the FAT32 file system.
RESET		<p>Press & hold for 2 seconds until the OS LED begins to flash. This places the EtherLINQ in <u>CONFIGURATION MODE</u> and forces the LAN IP = 192.168.1.1:8080 (see <i>Chapter 16: CONFIGURATION MODE</i>)</p> <p>Press & hold for 10 seconds until the top row of LEDs flash in sequence. Wait for the OS LED to stay on solid. This returns the EtherLINQ to its <u>factory default</u> settings: LAN IP = 192.168.1.1:8080 ~ Username/Password = admin/1234</p>
WAN	Solid	The wired WAN Ethernet port is the active WAN
	Flashing	The wired WAN Ethernet port is attempting to connect
LTE	Solid	The LTE Modem is the active WAN
	Flashing	The LTE Modem is attempting to connect
Bars	Off	The LTE Modem is not receiving a cellular signal
	1 Hz	The LTE signal is POOR
	10 Hz	The LTE signal is GOOD
	Solid	The LTE signal is EXCELLENT
PWR	Solid	Power is on
OS	Flashing	The EtherLINQ is booting up, performing an internal function or in Configuration Mode
	Solid	The EtherLINQ is operating normally
WiFi	Solid	The EtherLINQ's internal WiFi radio is enabled
SIM		Press yellow button on the right to eject the SIM tray. The EtherLINQ uses "mini" (2FF) sized SIMs. Adapters are provided for Micro (3FF) and Nano (4FF) sized SIMs.

2.2 Rear Panel



Figure 2: EtherLINQ Rear Panel

LABEL	DESCRIPTION
USB	USB 2.0 port for webcams, USB serial devices and flash drives
LAN 1	Connect equipment to this port with an Ethernet cable
WAN / LAN 2	Connect a cable/DSL modem or other Ethernet-based WAN equipment to this port. Can also be defined as a second LAN port via a software setting.
PWR	Connect the included 12V DC power adapter to this jack
GPS	Connect an external GPS antenna to this SMA Female jack
LOCK	Kensington Lock port

2.3 Hardware Setup

2.3.1 Attach Antennas

Attach the flat paddle shaped antennas to the MAIN and AUX SMA Female jacks on the left and right sides of the EtherLINQ along the Gold LTE banner. Attach the 2 round antennas to the MAIN and AUX RP-SMA Female jacks on the left and right sides along the Blue WiFi banner.

2.3.2 Install LAN Connection

Plug one end of an Ethernet cable into your computer's network port and the other end into the EtherLINQ's LAN 1 port on the rear panel.

2.3.3 Install WAN Connection (optional)

To use an external WAN connection such as a xDSL, cable modem or other wired Ethernet service as either primary or backup, connect an Ethernet cable from the output of the Ethernet WAN device to EtherLINQ's WAN port on the rear panel.

2.3.4 Insert SIM Card

Press the eject button to the right of the SIM card holder to eject the tray. Insert an active SIM card with the gold pins facing up and the diagonal notch on the front left. Replace the tray with the pins facing up and insert fully.

2.3.5 Power On

Plug one end of the provided power adapter into EtherLINQ's DC power port and the other end into an AC power outlet. After about 60 seconds, the EtherLINQ will be operational when its PWR LED and OS LED are both constantly on.

CHAPTER 3: ACCESSING THE ETHERLINQ

Initial setup of the EtherLINQ can be done using an Ethernet cable or via the internal WiFi Access Point.

Configure your PC to receive its IP address information automatically (DHCP) or set your PC's IP address to 192.168.1.2, netmask= 255.255.255.0 and default gateway=192.168.1.1.

To connect via WiFi, scan for a network named "EtherLINQ-nnnn" where nnnn are the last 4 characters of the EtherLINQ's serial number. The default security mode is WPA2-PSK and the default password is the 8 digit number printed on the EtherLINQ's label.

3.1 Start-up and Login

Open any web browser. In the address box, enter <http://192.168.1.1:8080> or <http://serial#.etherling.net:8080> where *serial#* is the 12 character serial number of the EtherLINQ printed on the bottom label (e.g. 001B39123456).



When you successfully connect to the configuration interface for EtherLINQ, the login screen will appear (Figure 3). Enter your username as [admin] and your password as [1234]. The EtherLINQ's Status page (Figure 4) will then be displayed. Changing the login password is highly recommended. See the **Advanced** tab.



Figure 3: EtherLINQ Login Screen

proxycast® EtherLINQ

Name: EtherLINQ-001B3911656C
Serial: 001B3911656C

Status **Mode** **LTE** **WAN** **WiFi** **VPN** **GPS** **USB** **Advanced** **Admin** **Log**

Device Status

EtherLINQ Model	EL-001 / LE910-SVG	Cellular Ethernet Modem/Router
Firmware Version	5.1.2	EtherLINQ software release <input type="button" value="Check for updates"/>
System Uptime	1w 1d 06:04:00	Time since last restart

WAN Status

Connection Mode	NAT Router Mode	Device operating mode
Active WAN	LTE Modem	Active WAN interface
WAN Connection	UP	WAN connection status
WAN Connection Time	1w 22:56:56	WAN connection uptime
WAN IP Address	166.246.222.80	IP address of the WAN interface

Modem Status

Network Provider	Verizon Wireless	Cellular network operator
Network Type	LTE	Cellular network technology
Modem Signal Quality	64% <input type="button" value="Graph"/>	0=No Signal 1-32=Weak 33-65=Good 66-100=Strong

WiFi Status

WiFi Radio	Enabled	WiFi radio status
WiFi SSID	EtherLINQ-656C	WiFi Access Point ID Name

VPN Status

Active Tunnels	Main-Office-VPN Remote-Users Remote-Users	Open IPsec Tunnels
----------------	---	--------------------

© Copyright, Proxycast, LLC.
All rights reserved.

proxycast®

Figure 4: Router Status Screen

3.2 Navigating the User Interface

The EtherLINQ's web management interface is divided into 3 sections (Figure 5):

1. Page Header
2. Navigation Menu Tabs
3. Configuration Parameters

proxicast® **EtherLINQ** Name: EtherLINQ-001B3911656C Serial: 001B3911656C

Status Mode LTE WAN WiFi VPN GPS USB **Advanced** Admin Log

Device Status

EtherLINQ Model	EL-001 / LE910-SVG	Cellular Ethernet Modem/Router
Firmware Version	5.1.2	EtherLINQ software release <input type="button" value="Check for updates"/>
System Uptime	1w 1d 06:04:00	Time since last restart

WAN Status

Connection Mode	NAT Router Mode	Device operating mode
Active WAN	LTE Modem	Active WAN interface
WAN Connection	UP	WAN connection status
WAN Connection Time	1w 22:56:56	WAN connection uptime
WAN IP Address	166.246.222.80	IP address of the WAN interface

Figure 5: EtherLINQ Screen Layout

The page header always displays the EtherLINQ's System Name and Serial Number. The System Name can be changed by clicking on the current value or on the **Advanced** tab.

Each menu tab is a collection of related system parameters and/or statistics. To select a menu tab, click on the menu tab title. The currently selected tab is indicated with a white bar at the bottom. Chapters 5 through 15 provide details on each of the EtherLINQ's menu options.

Configuration parameters are entered on the main panel of each screen. Screens are divided into logical parameter groupings labeled with black bands.

3.3 Top Level Menu Structure

Status	Provides real-time and historical information about the EtherLINQ's operation
Mode	Changes the EtherLINQ's Operating Mode, either "NAT Router" (default), "IP Pass-Through" (bridge) or "Virtual Cable" mode
LTE	Configures the EtherLINQ's embedded LTE modem (<i>select models</i>)
WAN	Configures the EtherLINQ's wired Ethernet WAN port
WiFi	Configures the EtherLINQ's embedded 802.11 b/g/n WiFi radio (<i>select models</i>)
VPN	Create and manage IPSec VPN settings (<i>select models</i>)
GPS	Enable and configure the EtherLINQ's embedded GPS Server (<i>select models</i>)

USB	Enable and configure the EtherLINQ's embedded USB Webcam server and USB Serial Port server
Advanced	Manages advanced settings such as passwords, ports, reboot, DDNS and syslog
Admin	Includes system management, firmware updates, system utilities, and diagnostic functions
Log	View the system event log

NOTE: The available menu tabs may vary between EtherLINQ models and depend upon which services have been licensed and activated for each serial number.

CHAPTER 4: QUICK SETUP

For many non-remote access applications, the EtherLINQ's default settings are sufficient.

LAN IP Address	192.168.1.1 Subnet mask = 255.255.255.0
HTTP Management Access	admin / 1234 on port 8080
Operating Mode	NAT Router
LAN DHCP Server	Enabled
WAN Priority	1. Ethernet WAN 2. LTE WAN
Ethernet WAN	DHCP Client Enabled
LTE APN	Carrier Default
WiFi Access Point	Enabled SSID = <i>EtherLINQ-nnnn</i> where nnnn are the last 4 characters of the serial number WPA2 Password = 8 digit number printed on EtherLINQ label
Security	All TCP/UDP ports closed. Remote Management disabled

Press the RESET button for 10 seconds to return the EtherLINQ to these settings.

See Section A.8: *EtherLINQ Default Settings* for a complete list of the EtherLINQ's default values.

4.1 Quick Setup

1. Power off the EtherLINQ.
2. For LTE connections: press the yellow eject button next to the SIM slot and remove the SIM tray. Place an active¹ SIM in the tray and carefully insert the tray back into the EtherLINQ.
3. For wired WAN connections: connect an Ethernet cable from your WAN access device (modem) to the EtherLINQ's WAN port.
4. Power on the EtherLINQ.

If you are using your cellular carrier's default APN (e.g. *broadband* for AT&T or *vzwinternet* for Verizon), the

¹ SIMs must be provisioned by the cell carrier prior to use in the EtherLINQ. Check with your cellular service provider regarding the correct service plan and Access Point Name (APN) required for your application. To activate a SIM, you will need the IMEI number of the EtherLINQ modem printed on the bottom label.

EtherLINQ will automatically connect to the cellular network with this value.

If you are using a different APN (e.g. *i2gold* for AT&T, *xxnn.vzwstatic* for Verizon or a custom APN), access the EtherLINQ's management pages via a web browser at <http://192.168.1.1:8080>. Click on the **LTE** tab and enter the correct APN, then click the **Save & Apply** button at the bottom of the page.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
Internal LTE Modem Settings										
Network Provider	Verizon Wireless		Current cellular network provider							
APN	<input type="text" value="mw01.vzwstatic"/>		Enter your assigned Access Point Name							
SIM PIN	<input type="text"/>		Enter your SIM PIN code (if required)							
MTU	<input type="text" value="1428"/>		Maximum Transmission Unit size							

Figure 6: Set LTE APN Value

The EtherLINQ will connect to the new APN when it reboots. With the Ethernet WAN and/or LTE Modem configuration complete, DHCP-enabled Ethernet LAN and WiFi devices connected to the EtherLINQ will have access to the Internet.

4.2 Password

Proxicast strongly recommends changing the EtherLINQ's default administration password.

To change the EtherLINQ's password, select the **Advanced** tab (Figure 7). Enter the new password (case sensitive) and click the **Save & Apply** button at the bottom of the page.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
Device Access										
System Name	<input type="text" value="EtherLINQ-001B3911656C"/>		Descriptive name for this device							
HTTP Config Port	<input type="text" value="8080"/>		HTTP port for configuration. Enter 0 to disable.							
HTTPS (SSL) Config Port	<input type="text" value="4443"/>		HTTPS (SSL) port for configuration. Enter 0 to disable.							
HTTP/S Config Password	<input type="text" value="1234"/>		HTTP/S password for configuration							
Remote Device Management	<input type="text" value="No"/>		Allow access to configuration settings via WAN							
Permitted WAN IP Addresses	<input type="text"/>		Comma separated list of IP addresses allowed to make WAN connections. Blank permits all IPs.							

Figure 7: Changing the Admin Password

By default, the EtherLINQ's management interface cannot be accessed remotely over a WAN connection. To enable remote access to the management pages, choose the **Remote Device Management** option. When this option is enabled, you must change the EtherLINQ's default password.

NOTE: Remote Device Management is not required for remote access to devices connected to the EtherLINQ.

4.3 LAN Configuration

To change the EtherLINQ's default LAN subnet (192.168.1.1 / 255.255.255.0), go to the **Mode** tab (Figure 8) and enter the IP address to assign to the EtherLINQ and select the desired subnet mask from the drop-down list. The EtherLINQ's DHCP server will automatically adjust to serve addresses from the new subnet.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
EtherLINQ Operating Mode Settings										
Connection Mode	NAT Router Mode ▾		Select a connection mode							
NAT Router Mode Settings										
LAN IP Address	192.168.1.1		IP address for the EtherLINQ's LAN port							
LAN IP Subnet Mask	255.255.255.0 (/24) ▾		Subnet mask for LAN							
Enable DHCP Server	Yes ▾		Respond to DHCP client requests							
DHCP Pool Start Address	192.168.1.33		Starting DHCP Server IP address							
DHCP Pool End Address	192.168.1.161		Ending DHCP Server IP address							

Figure 8: Ethernet LAN Setup

4.4 WiFi Configuration

Proxicast strongly recommends changing the EtherLINQ's default WiFi password.

To change the SSID value broadcast by the EtherLINQ to WiFi clients and the WPA2 access password, select the **WiFi** tab.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
WiFi Settings										
Enable WiFi	Yes ▾			Enable/Disable WiFi radio						
WiFi SSID	EtherLINQ-656C			WiFi network name (max 32 char)						
Hidden SSID	No ▾			Broadcast or hide SSID						
802.11 Mode	802.11b/g/n mixed ▾			Select the WiFi operation mode						
Channel	AUTO ▾			Select WiFi channel to use						
Enable WMM Mode	Yes ▾			Enable/Disable Wireless Multi-Media mode						
WiFi Security	WPA2-PSK ▾			Select the security mode						
WiFi Password	00049258			Enter WiFi password Default WiFi Password - Please Change						

Figure 9: Changing the WiFi Password

4.5 Accessing Remote Devices

In NAT Mode, accessing devices connected to the EtherLINQ from the Internet requires three things:

1. A publically accessible WAN IP address assigned by your WAN service provider (typically a static IP)
2. A statically assigned private IP address assigned by you on the LAN device to be accessed
3. One or more port-forwarding rules defined in the EtherLINQ to direct incoming traffic to the target device

Contact your WAN/LTE provider regarding the ability for your account to be accessed remotely. See also Section *A.4 Accessing Remote Devices* for other ways to remotely access devices using the EtherLINQ.

Remotely accessible devices in NAT Mode should have their IP address set to a value outside of the EtherLINQ's DHCP pool. The LAN IP address of the EtherLINQ must be the Default Gateway address on the target device.

In the EtherLINQ, define the ports your device uses to listen for connections by selecting the **Mode** tab. Enter the port to be used on the WAN interface of the EtherLINQ (incoming) and the port used by the device you wish to connect to (target), along with the private IP address you assigned to the target device. Repeat this information for each port required by your device.

Port Forwarding Rules		Enter up to 10 port forwarding / translation rules				
#	Active	Rule Name	Incoming Port(s)	Target Port(s)	Target IP Address	
1	<input checked="" type="checkbox"/>	Meter80	80 - 80	80 - 80	192.168.1.2	
2	<input checked="" type="checkbox"/>	Meter5100	5100 - 5100	5100 - 5100	192.168.1.2	
3	<input type="checkbox"/>					

Figure 10: Port Forwarding Rules

CHAPTER 5: STATUS TAB

5.1 Device Status

proxicast® **EtherLINQ** Name: EtherLINQ-001B3911656C
Serial: 001B3911656C

Status | Mode | LTE | WAN | WiFi | VPN | GPS | USB | Advanced | Admin | Log

Device Status

EtherLINQ Model	EL-001 / LE910-SVG	Cellular Ethernet Modem/Router
Firmware Version	5.1.2	EtherLINQ software release <input type="button" value="Check for updates"/>
System Uptime	2d 18:08:47	Time since last restart

WAN Status

Connection Mode	NAT Router Mode	Device operating mode
Active WAN	LTE Modem	Active WAN interface
WAN Connection	UP	WAN connection status
WAN Connection Time	2d 18:05:01	WAN connection uptime
WAN IP Address	166.246.222.80	IP address of the WAN interface

Modem Status

Network Provider	Verizon Wireless	Cellular network operator
Network Type	LTE	Cellular network technology
Modem Signal Quality	67% <input type="button" value="Graph"/>	0=No Signal 1-32=Weak 33-65=Good 66-100=Strong

WiFi Status

WiFi Radio	Enabled	WiFi radio status
WiFi SSID	EtherLINQ-656C	WiFi Access Point ID Name

VPN Status

Active Tunnels		Open IPsec Tunnels
----------------	--	--------------------

Figure 11: Router Status

5.1.1 Device Information

EtherLINQ Model	Product model name. To the left of the slash is the EtherLINQ hardware version. To the right is the LTE modem module version (if present)
Firmware Version	The firmware version this EtherLINQ is running. Click the Check for Updates button to find and install new EtherLINQ firmware (see Section <i>Updating EtherLINQ Firmware</i>)
System Uptime	The period of time EtherLINQ has been running since its last restart

5.1.2 WAN Status

Connection Mode	The EtherLINQ's current operating mode
Active WAN	Which of the WAN interfaces is currently responsible for routing traffic
WAN Connection	The status (UP/DOWN) of the currently active WAN
WAN Connection Time	The amount of time the currently active WAN has been routing traffic
WAN IP Address	The public facing IP address of the currently active WAN interface

5.1.3 Modem Status

Network Provider	The name of the cellular service provider currently serving the EtherLINQ's internal LTE modem
Network Type	The type of cellular service currently available (LTE, UMTS, GSM)
Modem Signal Quality	An aggregate measure of the strength and quality of the signal reaching the LTE modem. Click the GRAPH button to see more details and a history of the signal environment (see below).

5.1.4 WiFi Status

WiFi Radio	Whether the EtherLINQ's WiFi radio is enabled or disabled
WiFi SSID	SSID of the EtherLINQ

5.1.5 VPN Status

Active Tunnels	Names of the currently active IPsec tunnels to/from this EtherLINQ
----------------	--

5.2 Modem Signal Quality Graph

Click on the **Graph** button next to Modem Signal Quality and the graph in Figure 12 is displayed.




Figure 12: Modem Signal Quality Graph

The Modem Signal Quality Graph shows the current cellular signal environment for the EtherLINQ along with the overall quality measurement for the trailing 2 minutes with readings taken every 5 seconds. The graph is useful for positioning antennas and troubleshooting cellular signal related issues.

The graph is color coded to quickly indicate if a parameter is in the Excellent, Good, or Poor range. In general, reliable connection (and best throughput performance) is achieved when the signal quality remains in the Excellent or Good zones. Some fluctuation is normal.

The parameters at the bottom of the graph are:

Service	Radio technology currently active. Options are LTE, UMTS, GSM, UNKNOWN.
CSQ	Cellular Signal Quality. A composite measure of the overall signal quality expressed as a percentage.
RSSI	Received Signal Strength Indicator. A measurement of the amount of power in

	total radio signal received by the modem. Range is -113 dBm to -51 dBm.
RSRP	Reference Signal Received Power. The average power received by the modem from a single cell specific reference signal resource element spread over the full bandwidth. It is a signal strength measurement for LTE service and is not displayed for other services. Range is -140 dBm to -44 dBm.
RSRQ	Reference Signal Received Quality. A measurement that indicates the quality of the received reference signal relative to the RSSI and the number of resource blocks. It is a signal quality measurement for LTE service and is not displayed for other services. Range is -19.5 dB to -3 dB.
Ec/Io	Energy per code bit / Interference. The ratio of received power of the carrier (pilot) signal to the noise + interference. It is a signal-to-noise ratio used to measure quality of UMTS service. Ec/Io is not displayed for other services. Range is -24 dB to 0 dB.
RSCP	Reference Signal Code Power. Denotes the power measured by a receiver on a particular physical communication channel. It is a signal strength measurement for UMTS service and is not displayed for other services. Range is -120 dBm to -25 dBm.

CHAPTER 6: MODE TAB

EtherLINQ has three modes of operation which determine how the EtherLINQ behaves with regard to Internet access for LAN devices.



Figure 13: Connection Mode

1. NAT Router Mode (default)

The EtherLINQ operates as a standard Network Address Translation Router, providing private addresses via DHCP to attached Ethernet/WiFi devices and translating the IP of these devices to the single shared IP of the EtherLINQ's WAN interface. For in-bound remote access, port forwarding/translation rules must be created for each desired port/IP combination. NAT Mode is also used when IPSec VPN connections are required.

2. IP Pass-Through Mode

This mode causes the EtherLINQ to function as a "bridge" instead of a router. In this mode, the IP address of the active WAN interface is passed through to a single Ethernet (or WiFi) device attached to the EtherLINQ. The first device to request an IP from the EtherLINQ will be assigned the WAN IP, so IP Pass-Through Mode should only be used when a single device requires Internet access.

3. Virtual Cable Mode

Virtual Cable Mode creates a fully encrypted point-to-point connection between two or more EtherLINQs' and/or Proxicast PocketPORT's. In this virtual private networking (VPN) mode, the devices connected to each of the EtherLINQ's or PocketPORTs appear to be directly connected via an Ethernet cable. See Section 6.3 *Virtual Cable Mode*.

6.1 NAT Router Mode

The EtherLINQ provides Network Address Translation (NAT) services to protect private LAN IP addresses from access by users on the external WAN. NAT Router Mode is the EtherLINQ's default operating mode.

NAT Router Mode allows multiple Ethernet and WiFi devices to share the EtherLINQ's active WAN interface. Up to 2 Ethernet devices can be directly connected to the EtherLINQ along with multiple WiFi devices. An Ethernet switch can also be connected to one of the EtherLINQ's LAN ports to add additional devices.

If necessary, the EtherLINQ's LAN IP address and DHCP Server settings can be changed to match those required for your application.

NOTE: Regardless of the NAT Router Mode LAN IP Address setting, the EtherLINQ's LAN IP address will always be 192.168.1.1 when in Configuration Mode (See *Chapter 16: CONFIGURATION MODE*).

By default, the EtherLINQ blocks all incoming traffic from the WAN interfaces. Port-Forwarding is a technique to selectively allow access to selected devices and services on the private LAN. The EtherLINQ supports both Port Forwarding and Port Translation. These features are integrated with the EtherLINQ's firewall. Creating new port forwarding/translation rules automatically opens the corresponding ports in the firewall – no other configuration is necessary.

The port forwarding function gives remote users access to devices on the local network via the public WAN IP address or DNS name. You can assign a specific external port range to a local server (IP address). Furthermore, you can specify a different internal port range to be associated with external ports in a port forwarding rule. When the EtherLINQ receives an external request to access any one of the configured external ports, it will redirect the request to the corresponding internal server and change its destination port to one of the internal ports specified. This allows multiple LAN devices with the same port (e.g. port 80) to be accessed remotely without having to change their settings.

NOTE: To allow remote administrative access to the EtherLINQ, you must enable Remote Device Management on the **Advanced** tab (See *Chapter 13: ADVANCED TAB*). No port forwarding rules are required.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
EtherLINQ Operating Mode Settings										
Connection Mode		NAT Router Mode ▾			Select a connection mode					
NAT Router Mode Settings										
LAN IP Address		192.168.1.1			IP address for the EtherLINQ's LAN port					
LAN IP Subnet Mask		255.255.255.0 (/24) ▾			Subnet mask for LAN					
Enable DHCP Server		Yes ▾			Respond to DHCP client requests					
DHCP Pool Start Address		192.168.1.33			Starting DHCP Server IP address					
DHCP Pool End Address		192.168.1.161			Ending DHCP Server IP address					
Port Forwarding Rules					Enter up to 10 port forwarding / translation rules					
#	Active	Rule Name	Incoming Port(s)	Target Port(s)	Target IP Address					
1	<input type="checkbox"/>									
2	<input type="checkbox"/>									
3	<input type="checkbox"/>									
4	<input type="checkbox"/>									
5	<input type="checkbox"/>									
6	<input type="checkbox"/>									
7	<input type="checkbox"/>									
8	<input type="checkbox"/>									
9	<input type="checkbox"/>									
10	<input type="checkbox"/>									

Figure 14: NAT Router Mode

LAN IP Address	Sets the internal LAN IP address of the EtherLINQ. Note: The EtherLINQ's built-in DHCP Server will automatically adjust to the IP address and subnet entered.
LAN IP Subnet Mask	Select the appropriate subnet mask from the list.
Enable DHCP Server	The DHCP Server function can be enabled or disabled. If disabled, you must statically assign an IP address, subnet mask and default gateway (the LAN IP of the EtherLINQ) to all connected LAN/WiFi devices.
DHCP Pool Start Address	The DHCP starting IP address offered by the DHCP Server.
DHCP Pool End Address	The DHCP ending IP address offered by the DHCP Server. NOTE: The EtherLINQ does not offer IP addresses in any particular order within the defined pool.

Port Forwarding Rules	Up to 10 Port Forwarding / Port Translation rules can be defined to direct where incoming traffic on various ports is routed. The EtherLINQ routes both TCP and UDP traffic on the designated ports. There is only one set of Port Forwarding Rules – the rules are applied to whichever WAN interface is currently active.
Active	Check this box to make the rule active and unlock the rule's data fields. Inactive rules will not be enforced but are saved in the EtherLINQ's configuration.
Rule Name	Any alphanumeric string used to identify the rule for your own purposes.
Incoming Port(s)	<p>Define the port number(s) that will be exposed on the WAN interface. You will append one of these port numbers after the EtherLINQ's WAN IP or DDNS in order to access the corresponding LAN / WiFi device's IP address.</p> <p>The incoming and target port ranges must contain the same number of ports, but can be different to enable port translation. Incoming port ranges may not overlap.</p>
Target Port(s)	By default, the Incoming Ports are copied to the Target Ports. To perform "port translation" and have the EtherLINQ route traffic from an incoming port to a different port on the target device, set the Target Ports to the ports that the target device is actually listening on.
Target IP Address	<p>The IP address of the LAN device to receive incoming traffic. Assigning a static IP address to port forwarding targets is recommended since DHCP does not guarantee the same IP address each time. The target device must also have its default gateway value set to the EtherLINQ's LAN IP address.</p> <p>NOTE: The number of Incoming Ports and Target Ports must match on each rule and may not overlap with any other rules or include any of the EtherLINQ reserved ports (see Section <i>EtherLINQ Default Settings, page 75</i>).</p>

NOTE: Each port forwarding rule applies to both TCP and UDP traffic on the indicated port number.

EXAMPLE:

Consider the network configuration shown in Figure 15 with the EtherLINQ operating in NAT Router Mode. To remotely access either the Meter or Controller from the Internet, port-forwarding rules must be configured.




Figure 15: NAT Router Mode Example

Figure 16 shows the two required Port Forwarding Rules. Rule # 1 named “Meter” is for a device which has an embedded web server listening on port 80. This is the only port needed for this device, so the Incoming and Target ports are all set to “80”. A Target IP Address of 192.168.1.2 was statically assigned to the meter along with a subnet mask of 255.255.255.0 and a default gateway of 192.168.1.1 (see LAN IP settings above).

Port Forwarding Rules		Enter up to 10 port forwarding / translation rules			
#	Active	Rule Name	Incoming Port(s)	Target Port(s)	Target IP Address
1	<input checked="" type="checkbox"/>	Meter	80 - 80	80 - 80	192.168.1.2
2	<input checked="" type="checkbox"/>	Controller	8180 - 8181	80 - 81	192.168.1.3
3	<input type="checkbox"/>				

Figure 16: Port Forwarding & Translation Rules

Rules #2 is for a programmable logic controller that has 2 listening ports. One is for an embedded web server listening on port 80; the other is a control interface on port 81. Since port 80 is already in use by the meter’s web server (rule #1), a different range of incoming ports to use must be defined, and the EtherLINQ must translate those ports into the ones used by the controller. In the example, ports 8180 and 8181 get translated to ports 80 and 81 respectively when sent to the controller at 192.168.1.3.

To access the Meter, use the EtherLINQ’s public IP address. To access the Controller, use the EtherLINQ’s public IP address with either :8180 or :8181 appended to it depending on which Controller port you need to access (e.g. <http://166.246.222.80:8180>).

6.2 IP Pass-Through (Bridge) Mode

IP Pass-Through / Bridge Mode is the simplest way to use the EtherLINQ. In this mode, the EtherLINQ is essentially “invisible” to the Ethernet devices attached to it. The EtherLINQ makes a WAN connection and passes the IP address received from the WAN interface to the device attached to the LAN Ethernet port. Typically, only 1 Ethernet device is attached to the EtherLINQ when operating in IP Pass-Through/Bridge Mode - the first device to request an IP from the EtherLINQ will be assigned the WAN IP.



Figure 17: IP Pass-Through Mode Example

Configure the attached Ethernet device for DHCP to automatically receive its IP configuration information (IP address, subnet mask and default gateway)². Once the EtherLINQ receives the IP information from the WAN, it will respond to DHCP requests from the Ethernet device with the cellular IP data. You may need to release and renew the Ethernet device’s IP setting in order to obtain the correct cellular values.

If the WAN IP changes, the Ethernet port’s Link Status line is “winked” to signal the attached LAN device that it needs to request a new IP address from the EtherLINQ.

Use IP Pass-Through Mode when you simply want to connect a single Ethernet device to the Internet and have the Ethernet device receive an IP address from the cellular network. It is also possible to pass the WAN IP address to a WiFi attached device. Remotely access the Ethernet device using the public IP address of the EtherLINQ.



Figure 18: IP Pass-Through Mode

² A common question is “where does the static IP address from the cellular provider get entered?” The static LTE address is not entered into either the EtherLINQ or the target device – all cellular “static IP” addresses are issued via DHCP, so the target device must be set to request an IP address when the EtherLINQ is operating in IP Pass-Through Mode.

NOTE: Port Forwarding and Firewall rules do not apply in IP Pass-Through Mode; the LAN device is fully exposed to the WAN interface, so ensure that the device has the necessary security protections installed.

6.3 Virtual Cable Mode

A unique feature of the EtherLINQ is “Virtual Cable Mode” (VCM). In this mode, two or more EtherLINQ’s (and/or PocketPORT’s) act as a very long virtual Ethernet cable. The intervening WAN networks are completely transparent; the ends appear to be directly connected via cable. Any application that works over a direct Ethernet cable also works over Virtual Cable.

Virtual Cable Mode is especially useful for software applications that expect external LAN hardware to be on the same physical Ethernet segment (i.e. “flat networks”). For example, some PLC programming and monitoring applications broadcast probe packets to locate their associated hardware. These packets typically do not traverse routed networks or the Internet, but will be forwarded to the remote equipment when it is connected via Virtual Cable Mode, even across a cellular Internet connection.

The EtherLINQ uses end-to-end encryption on all Virtual Cable connections. Networks are protected by a shared password (pre-shared key), known only to the participating nodes. No software needs to be installed on any end device, so users can comply with security policies regarding third-party software installations. Closed systems such as cameras and PLC’s can have fully protected connections over the Internet even though they can’t run VPN software. Virtual Cable Mode is completely self-contained and autonomous.




Figure 19: Virtual Cable Mode Example

Unlike traditional VPNs where the networks on each side of a connection are in different subnets, the network addresses on both sides of a Virtual Cable connection must be in the same subnet (see red IP addresses in Figure 19). When in Virtual Cable Mode, LAN IP, DHCP and Port-Forwarding settings from NAT Router Mode do not apply.

Virtual Cable Mode operates primarily as a peer-to-peer network connection. A central “Switchboard” service is used as a directory lookup so that devices can locate each other initially. Once a two-way connection is established, traffic moves directly between the peers. In instances where firewalls block inbound traffic between the devices, the Switchboard server acts as a “relay” by creating reverse tunnels to the end-points and routing traffic through the tunnels. The Switchboard server does not hold a copy of the encryption key, so data packets remain fully secure until they reach their final destination.

Proxicast maintains a public virtual cable switchboard server (vc.etherlinq.net) for use by our customers. All customer data and connections are encrypted and secured and the high-performance switchboard server has a 150 Mbps connection to the Internet. Customers connecting a large number of EtherLINQ's to a single Virtual Cable network may wish to license the Switchboard server for hosting their own network.

Devices attached to routers operating in Virtual Cable Mode are only accessible by other devices that are part of the same Virtual Cable network; they cannot be accessed remotely via the Internet. One-to-One, One-to-Many, and Many-to-Many connections are supported. All Virtual Cable routers that need to communicate with each other must have the same Account Name, Network Name, Encryption Type and Key.

NOTE: All Ethernet frames and broadcast traffic are passed to all nodes of the network. Connecting a large number of devices to Virtual Cable routers can create high WAN usage which may impact cost & speed.

The EtherLINQ's Virtual Cable Mode is fully interoperable with Virtual Cable Mode on Proxicast's PocketPORT.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
EtherLINQ Operating Mode Settings										
Connection Mode		Virtual Cable Mode ▾		Select a connection mode						
Virtual Cable Settings										
Switchboard Server Address		vc.etherlinq.net:9999		Enter vc.etherlinq.net:9999 to use Proxicast's public server						
Account Name		<input type="text"/>		Enter your email address or another globally unique identifier						
Network Name		<input type="text"/>		Enter a unique network name (same value on both EtherLINQs)						
Encryption Algorithm		AES - 256 bit ▾		Select an encryption algorithm						
Encryption Key		<input type="text"/>		Enter up to 32 ASCII characters						

Figure 20: Virtual Cable Mode

Switchboard Server Address	Enter the IP address or FQDN of the Switchboard server and the server's listening port. To use Proxicast's public Switchboard, enter <code>vc.etherlinq.net:9999</code>
Account Name	Any alphanumeric string to identify you uniquely to the Switchboard server. We recommend using your email address. No pre-registration is required; simply enter your selected Account Name.
Network Name	Any alphanumeric string to identify the group of devices which are to communicate with each other under your account. Only devices that have the same Network Name can communicate. You may create multiple networks under the same Switchboard account.
Encryption Algorithm	Select the Encryption Algorithm to be applied to data packets. AES-256 with an ASCII key is the default. You may also select AES-256 with a 64 hexadecimal key. TwoFish-256 is available for compatibility with Proxicast's PocketPORT devices.
Encryption Key	Enter either the ASCII or HEX encryption key to be used.

NOTE: Virtual Cable Mode throughput performance can be increased by not providing a Network Password value on each EtherLINQ. This disables encryption – all data will be transferred between nodes in its native format. All nodes must have the same (or no) Network Password in order to communicate.

CHAPTER 7: LTE TAB

The **LTE** tab configures the EtherLINQ's internal LTE modem. In many cases, the EtherLINQ is able to automatically determine the correct LTE settings based on the cellular carrier and SIM. The default settings can be overridden on this screen.

7.1 LTE Setup

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
Internal LTE Modem Settings										
Network Provider		Verizon Wireless		Current cellular network provider						
APN		<input type="text"/>		Enter your assigned Access Point Name						
SIM PIN		<input type="text"/>		Enter your SIM PIN code (if required)						
MTU		1428		Maximum Transmission Unit size						

Figure 21: LTE Settings

Network Provider (read only)	The name of the cellular service provider currently providing service to the EtherLINQ. This value is automatically determined by the LTE module and may change when roaming on to a different carrier.
Access Point Name (APN)	Enter the APN string assigned to your SIM by your service provider. Different APN values provide different levels of service and functionality. Contact your service provider for the correct APN for your account.
SIM PIN	If you have assigned a 4 digit PIN to secure your SIM, enter the PIN here.
MTU	Enter the appropriate Maximum Transmission Unit (MTU) size for your service provider's network. In most cases, the default value is appropriate.

7.2 LTE Keep-Alive

LTE Keep-Alive settings configure the EtherLINQ's "Auto Ping" feature which periodically sends traffic to a destination on the WAN to monitor the WAN connection's status. The default values are appropriate in most situations.

When the EtherLINQ detects a cellular connection failure based on the Auto Ping settings, it will drop the connection and attempt to switch to the wired WAN interface. It will also restart the cellular connection and switch back to LTE when a connection is available unless the wired WAN has higher priority or is disabled. If the Reboot on Disconnect parameter (see **Advanced** Tab) is enabled, the EtherLINQ will reboot instead of switching interfaces.

LTE Keep-Alive Settings		
Protocol	ICMP ▾	Use Ping (ICMP) or Web (HTTP) packets
Destination Address	8.8.8.8	IP or DNS address to ping
Ping Frequency	5	# of seconds between pings
Ping Failure Timeout	3	# of seconds to wait for a reply

Figure 22: LTE Keep-Alive Settings

Protocol	ICMP (ping) or HTTP packets can be used as the data for Keep-Alive. ICMP packets are faster but may be blocked and only determine if a remote host is online. HTTP packets can be used to test if a remote host is responding on port 80 with value HTTP. Select "Disabled" to disable the LTE Keep-Alive function completely and send no WAN test traffic.
Destination Address	Enter the IP address or FQDN of the remote host to receive Keep-Alive traffic
Ping Frequency	Delay time between sending Keep-Alive packets
Ping Failure Timeout	Maximum number of seconds to wait for each ping/HTTP to be acknowledged (maximum latency) before assuming the ping to have failed
Fault Tolerance	Number of consecutive pings that must fail to be acknowledged before the interface is marked as down

CHAPTER 8: WAN TAB

The **WAN** tab configures the EtherLINQ's WAN Ethernet port and how the EtherLINQ responds when a WAN interface goes down.

8.1 WAN Setup

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
Ethernet WAN Settings										
LAN/WAN Port	WAN ▼			Define function of Ethernet LAN/WAN port						
WAN IP Type	DHCP ▼			How WAN IP values are obtained						
MTU	1500			Maximum Transmission Unit size						

Figure 23: WAN Setup

LAN/WAN Port	The LAN/WAN Ethernet port can be configured as a WAN port, a second LAN Ethernet port or the port can be disabled entirely
WAN IP Type	When operating as a WAN port (default), select whether the WAN requests a DHCP address assignment or assign a static IP address to the WAN interface. When Static IP is selected, additional fields as shown in Figure 24 are displayed.
MTU	Maximum transmission unit size: up to 1500 bytes

Static IP Settings		
WAN IP Address	<input type="text"/>	IP address for the EtherLINQ's WAN port
WAN IP Subnet Mask	255.255.255.255 (/32) ▼	Subnet mask for the WAN
WAN Gateway IP	<input type="text"/>	Gateway IP address for the WAN
WAN DNS 1	<input type="text"/>	DNS Server 1 for the WAN
WAN DNS 2	<input type="text"/>	DNS Server 2 for the WAN

Figure 24: WAN Static IP Settings

WAN IP Address	Sets the desired WAN IP address for the EtherLINQ. The WAN subnet must be different from the LAN subnet.
WAN Subnet Mask	Select the appropriate subnet mask from the list
WAN Gateway IP	Enter the remote gateway address for the WAN interface
WAN DNS 1	Enter the primary DNS Server for the WAN interface
WAN DNS 2	Enter the secondary DNS Server for the WAN interface

8.2 WAN Fail-Over

Sets which order the EtherLINQ uses to make WAN connections and how often the EtherLINQ attempts to re-establish a connection to the primary interface.

WAN Fail-Over Settings		
WAN Priority	Ethernet, LTE ▼	Order to check WAN interfaces
Fall-Back Check	60	# of seconds between down interface status checks

Figure 25: WAN Fail-Over Settings

WAN Priority	Options are LTE preferred over Ethernet and Ethernet preferred over LTE. Only 1 WAN interface may be active at a time.
Fall-Back Check	Number of seconds the EtherLINQ waits before checking if a “down” WAN interface is available

8.3 WAN Keep-Alive

WAN Keep-Alive settings configure the EtherLINQ’s “Auto Ping” feature which periodically sends traffic to a destination on the WAN to monitor the WAN connection’s status. The default values are appropriate in most situations.

When the EtherLINQ detects a WAN connection failure based on the Auto Ping settings, it will drop the connection and attempt to switch to the LTE modem. It will also restart the WAN connection and switch back to the wired WAN when a connection is available unless the LTE modem has higher priority or is not configured. If the Reboot on Disconnect parameter (see **Advanced** tab) is enabled, the EtherLINQ will reboot instead of switching interfaces.

WAN Keep-Alive Settings		
Protocol	ICMP ▼	Use Ping (ICMP) or Web (HTTP) packets
Destination Address	8.8.8.8	IP or DNS address to ping
Ping Frequency	5	# of seconds between pings
Ping Failure Timeout	3	# of seconds to wait for a reply
Failure Tolerance	3	# of successive timeouts before failure

Figure 26: WAN Keep-Alive Settings

Protocol	ICMP (ping) or HTTP packets can be used as the data for Keep-Alive. ICMP packets are faster but may be blocked and only determine is a remote host is
----------	---

	online. HTTP packets can be used to test if a remote host is responding on port 80 with value HTTP. Select "Disabled" to disable the WAN Keep-Alive function completely and send no WAN test traffic.
Destination Address	Enter the IP address or FQDN of the remote host to receive Keep-Alive traffic
Ping Frequency	Delay time between sending Keep-Alive packets
Ping Failure Timeout	Maximum number of seconds to wait for each ping/HTTP to be acknowledged (maximum latency) before assuming the ping to have failed
Fault Tolerance	Number of consecutive pings that must fail to be acknowledged before the interface is marked as down

CHAPTER 9: WIFI TAB

The **WiFi** tab configures the EtherLINQ's Access Point feature on WiFi-enabled EtherLINQ models. The Access Point is bridged to the EtherLINQ's LAN -- WiFi devices are assigned IP addresses from the LAN DHCP pool.

The WiFi Access Point is enabled by default. The default SSID is "EtherLINQ-" + the last 4 characters of the EtherLINQ's serial number. The default WiFi password is unique to each serial number and is printed on the bottom label of the EtherLINQ.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
WiFi Settings										
Enable WiFi	Yes ▼			Enable/Disable WiFi radio						
WiFi SSID	EtherLINQ-656C			WiFi network name (max 32 char)						
Hidden SSID	No ▼			Broadcast or hide SSID						
802.11 Mode	802.11b/g/n mixed ▼			Select the WiFi operation mode						
Channel	AUTO ▼			Select WiFi channel to use						
Enable WMM Mode	Yes ▼			Enable/Disable Wireless Multi-Media mode						
WiFi Security	WPA2-PSK ▼			Select the security mode						
WiFi Password	00049258			Enter WiFi password Default WiFi Password - Please Change						

Figure 27: WiFi Setup

Enable WiFi	The WiFi Access Point feature can be enabled or disabled. NOTE: It is possible to completely remove the WiFi functionality from the EtherLINQ. See <i>Section 14.1.2 Activating & Deactivating Features</i> .
WiFi SSID	The descriptive name which is displayed when WiFi clients search for available access points
Hidden SSID	Enable/Disable broadcasting of the SSID. Disabling SSID broadcasting enhances the security by hiding SSID information and requiring users to enter the SSID manually when connecting to the access point.
802.11 Mode	Select the combination of 802.11 radio protocols to use
Channel	Select the 802.11 radio channel to use. Select AUTO to have the EtherLINQ determine the best channel to use based on the local radio environment.
Enable WMM Mode	Enable/Disable Wireless Multi-Media mode. For example, VoIP or video traffic will have higher priorities over ordinary traffic.
WiFi Security	Select the security protocol that WiFi clients must use to authenticate

WiFi Password	Enter the password protocol that WiFi clients must use to authenticate to the access point. For WEP, passwords must be 5 or 13 characters; for WPA/WPA2, passwords must be between 8 and 63 characters.
---------------	---

The WiFi Access Point can be enabled in all three EtherLINQ operating modes. However, in IP Pass-Through Mode, only 1 device can obtain the WAN IP address. In Virtual Cable Mode, a separate DHCP server would be required on the LAN or all WiFi devices would have to have statically assigned LAN IPs.

CHAPTER 10: VPN TAB

Internet Protocol Security (IPSec) is a standards-based protocol suite for securing Internet Protocol (IP) communications by authenticating and encrypting each IP packet of a communication session. IPSec also includes protocols for establishing mutual authentication between agents at the beginning of the session and negotiation of cryptographic keys to be used during the session.

IPSec is an extremely popular and robust end-to-end security scheme operating in the Internet Layer of the Internet Protocol Suite. It can be used to protect data flows between a pair of security gateways (Net-to-Net Mode), or between a security gateway and a remote device (Remote User Mode). The EtherLINQ supports both modes and is interoperable with a wide variety of IPSec-compliant software and hardware products from numerous vendors. IPSec is only available when the EtherLINQ is operating in NAT Router Mode.

When configuring an IPSec VPN connection, keep the following in mind:

- All VPN parameters must match EXACTLY between the 2 devices.
- It is helpful to have simultaneous access to the parameter and log screens of both devices during setup and testing.
- The network on the LAN side of the EtherLINQ and on the “private” side of the other VPN equipment must be on different subnets.
- Most users find it easiest to configure net-to-net VPNs if both end-points have static public IP addresses. Contact your ISP or cellular network operator to determine if static IP addresses are available. Otherwise, use a Dynamic DNS hostname for your EtherLINQ that has a dynamic public IP address (See *Section 13.3 Dynamic DNS*).
- The EtherLINQ can be either the VPN initiator or responder for net-to-net VPNs. It is the responder for Remote User VPNs. If the EtherLINQ has only a *private* WAN IP address, the EtherLINQ must initiate all IPSec connections (Remote User Mode is not possible with private WAN IP addresses). Consult the documentation of the VPN server the EtherLINQ will communicate with regarding configuration of private IP end-points.
- All intervening network hardware between the VPN end-points must support IPSec VPN pass-through and allow ESP (encrypted, Type 50) packets in addition to IKE and NAT-T requests on UDP ports 500 & 4500.
- Proxycast IPSec VPN Client for Windows is the easiest way to configure a remote user VPN tunnel on a Windows PC. A fully-functional 30 day evaluation copy can be downloaded from the Proxycast web site.
- Additional EtherLINQ VPN configuration examples are available on the Proxycast Support web site in the TechNotes and Knowledgebase areas.

10.1 IPsec VPN Settings

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
IPsec VPN Settings										
Enable IPsec	Yes ▾					Enable/Disable IPsec VPN features				
IPsec Log Level	Normal ▾					Changing log level will reset all tunnels				
#	Connection Name	Initiate	Remote Gateway	Remote Subnet / Mask	Phase 1	Phase 2	Action			
1										
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="Refresh"/>										

Figure 28: IPsec VPN Connections

Fields

IPsec	Select Enable/Disable to enable/disable IPsec. NOTE: It is possible to completely remove the IPsec functionality from the EtherLINQ. See <i>Section 14.1.2 Activating & Deactivating Features</i> .
IPsec Log Level	Normal for routine use; Debug for additional information on tunnel activity. NOTE: Debug will quickly fill up the system log.
Connection Name	User-defined string to identify a specific tunnel
Initiate	How the tunnel was initiated (Auto, on Traffic detection, Manual, Disabled)
Remote Gateway	IP/FQDN of the remote IPsec end-point
Remote Subnet / Mask	IP subnet & netmask of the LAN connected to the remote IPsec end-point
Phase 1	Status of IPsec Phase 1 negotiations (● = Down, ● = Up)
Phase 2	Status of IPsec Phase 2 negotiations (● = Down, ● = Up)
Action	Forcibly Open or Close the tunnel

Buttons

Add	Click Add to create a new IPsec connection rule
Edit	Highlight the desired connection and click Edit to modify the connection parameters. You may also double-click the row to edit.
Delete	Highlight a connection and click Delete to remove the selected rule
Refresh	Forcibly refresh the status of all tunnels

10.2 Add an IPSec Net-to-Net Rule

In this example, a Net-to-Net VPN connection will be established between an existing VPN concentrator on the headquarters network and a EtherLINQ at a remote office location.




Figure 29: Net-to-Net IPSec Example

Click on the **Add** button to display the following screen:

Connection	Local Network	Phase 1
Connection Name Main-Office-VPN VPN Mode Net-to-Net Initiation Auto Initiate (Always Up) IKE Key Mode IKEv1 PSK Preshared Key 12345678	Local Subnet IP 192.168.1.0 Local Netmask 255.255.255.0 (/24) Remote Network Remote Gateway main-office.prxd.com <input type="checkbox"/> Disable Split Tunneling Route all non-local traffic into tunnel Remote Subnet IP 10.0.0.0 Remote Netmask 255.0.0.0 (/8)	Mode Main Local ID 1.2.3.4 Remote ID 5.6.7.8 Lifetime 28800 Seconds Authentication MD5 Encryption DES Key Management DH1 (768 bits) <input checked="" type="checkbox"/> Enable Multiple Proposals
Dead Peer Detection (DPD) DPD Enable <input checked="" type="checkbox"/> Interval 10 Seconds Timeout 60 Seconds		Phase 2 Authentication SHA1 Encryption DES Lifetime 28800 Seconds Key Management (PFS) None <input checked="" type="checkbox"/> Enable Multiple Proposals
<input type="button" value="Save"/> <input type="button" value="Reset"/> <input type="button" value="Cancel"/>		

Figure 30: IPSec Net-to-Net VPN Settings

Connection

Connection Name	User defined name for the IPSec rule. Spaces are not permitted.
VPN Mode	Net-to-Net
Initiation	<p>Auto Initiate (Always Up): forces the EtherLINQ to always attempt to initiate a VPN connection to the remote gateway. If the connection drops, the EtherLINQ will continuously attempt to reconnect.</p> <p>Initiate on Traffic: IPSec tunnel will only be established when the EtherLINQ detects traffic that is destined for the LAN subnet behind the remote gateway.</p> <p>Manual Connection: to establish an IPSec tunnel, the user must click the Open button on the VPN settings screen.</p> <p>Disabled: this IPSec tunnel will be ignored.</p>
IKE Key Mode	IKEv1 and IKEv2 Pre-Shared Key (PSK) are supported.
Preshared Key	Enter the preshared key. The key should be at least an 8-digit ASCII string.

NOTE: If the remote VPN gateway will be responsible for initiating the VPN connection, select Manual for the EtherLINQ's Initiation Mode. Only one VPN device should act as the initiator.

Dead Peer Detection

DPD Enable	Enable/disable Dead Peer Detection (DPD).
DPD Interval	Number of seconds between checks for a dead peer.
DPD Timeout	Number of seconds to wait for a response before declaring the peer dead.

Local Network

Local Subnet IP	<p>Enter the subnet IP address on the LAN-side of the local EtherLINQ which will be visible to the remote VPN subnet.</p> <p>NOTE: Enter the subnet address and not the LAN IP of the EtherLINQ. E.g. if the EtherLINQ's IP is 192.168.1.1 / 255.255.255.0, enter 192.168.1.0 as the subnet IP.</p>
Local Subnet Netmask	Netmask for the LAN subnet entered above.

Remote Network

Remote Gateway	<p>Enter the IP address or fully qualified domain name of the remote VPN gateway. This option is required in Net-to-Net mode.</p>
Disable Split Tunneling	<p>Unchecked: Traffic can flow to Internet addresses outside of IPSec tunnel (default).</p> <p>Checked: The EtherLINQ directs all traffic into the IPSec tunnel. The VPN device on the other side is responsible for routing the traffic to its final destination.</p>

Remote Subnet IP	Enter the subnet IP address of the remote VPN gateway. This option is required in Net-to-Net mode. NOTE: Enter the subnet address and not the LAN IP behind the remote VPN gateway. E.g. if the remote VPN gateway's IP is 10.1.1.1/ 255.0.0.0, enter 10.0.0.0 as the subnet IP.
Remote Subnet Netmask	Subnet netmask of the remote VPN gateway. This option is required in Net-to-Net mode.

Phase 1

Mode	Select Main or Aggressive Mode. Must match the setting on the remote gateway.
Local ID	Enter the phase 1 Local ID
Remote ID	Enter the phase 1 Remote ID
Lifetime	Enter the phase 1 lifetime (between 3600 and 86400 seconds)
Authentication	Choose the phase 1 authentication
Encryption	Choose the phase 1 encryption
Key Management	Choose the phase 1 group key management
Enable Multiple Proposals	Check to allow the EtherLINQ to offer multiple combinations of authentication, encryption and key management to the remote VPN gateway. Selecting this option can overcome mismatches between the VPN devices if the remote VPN gateway also supports multiple proposals.

NOTE: For IKEv1, if the Local and Remote ID values are blank, the EtherLINQ uses its own public WAN IP address as the Local ID and the IP address of the remote VPN gateway as the Remote ID. If the remote VPN gateway has a dynamic IP address, or you use a FQDN to reference it, or it is behind a NAT firewall, Local and Remote ID values may be required on both VPN end-points.

For IKEv2, Local and Remote ID values are required.

Phase 2

Lifetime	Enter the phase 2 lifetime (between 3600 and 86400 seconds)
Authentication	Choose the phase 2 authentication
Encryption	Choose the phase 2 encryption
Key Management (PFS)	Choose the phase 2 group key management. This setting is also known as Perfect Forward Secrecy.
Enable Multiple Proposals	Check to allow the EtherLINQ to offer multiple combinations of authentication,

encryption and key management to the remote VPN gateway. Selecting this option can overcome mismatches between the VPN devices if the remote VPN gateway also supports multiple proposals.

IPSec VPN Settings							
Enable IPSec	Yes ▾	Enable/Disable IPSec VPN features					
IPSec Log Level	Normal ▾	Changing log level will reset all tunnels					
#	Connection Name	Initiate	Remote Gateway	Remote Subnet / Mask	Phase 1	Phase 2	Action
1	Main-Office-VPN	Auto	main-office.prxd.com	10.0.0.0/255.0.0.0	●	●	Close
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="Refresh"/>							

Figure 31: IPSec VPN Network Connections Status

10.3 Add an IPSec Remote User Rule

In this example, a Remote User VPN connection will be established between with the EtherLINQ functioning as the VPN Server and remote PC as the client using the Proxicast IPSec VPN Client for Windows software.




Figure 32: Remote User IPSec Example

Click the **Add** button to display the following screen and select **VPN Mode** = Remote User:

Figure 33: IPsec Remote User VPN Settings

The settings for a Remote User VPN are essentially the same as for a Net-to-Net VPN except that the Remote Gateway and Network information is not required since the remote client will be a single unknown IP address.

Multiple VPN clients can share a single Remote User VPN rule on the EtherLINQ if all clients are to have access to the same subnet on the EtherLINQ's LAN.

Note: You cannot make a Remote User VPN connection to an EtherLINQ that has a private IP address; you must request a public IP address from your ISP. If a public IP address for the EtherLINQ cannot be obtained, then the EtherLINQ must initiate a Net-to-Net VPN connection to another VPN server in order to remotely access devices attached to the EtherLINQ; or use the EtherLINQ's Virtual Cable Mode (see *Section 6.3 Virtual Cable Mode*)

Connection

Connection Name	User defined name for the IPsec rule. Spaces are not permitted.
VPN Mode	Remote-User
Initiation	Manual Connection: an IPsec tunnel will be created when a remote VPN client

	<p>makes a valid connection request; the EtherLINQ cannot make a connection to a remote client.</p> <p>Disabled: this IPSec tunnel will be ignored.</p>
IKE Key Mode	IKEv1 and IKEv2 Pre-Shared Key (PSK) are supported.
Preshared Key	Enter the preshared key. The key should be at least an 8-digit ASCII string.

Dead Peer Detection

DPD Enable	Enable/disable Dead Peer Detection (DPD).
DPD Interval	Number of seconds between checks for a dead peer
DPD Timeout	Number of seconds to wait for a response before declaring the peer dead

Local Network

Local Subnet IP	<p>Enter the subnet IP address on the LAN-side of the local EtherLINQ which will be visible to the remote VPN client.</p> <p>NOTE: Enter the subnet address and not the LAN IP of the EtherLINQ. E.g. if the EtherLINQ's IP is 192.168.1.1 / 255.255.255.0, enter 192.168.1.0 as the subnet IP.</p>
Local Subnet Netmask	Netmask for the LAN subnet entered above.

Phase 1

Mode	Select Main or Aggressive Mode. Must match the setting on the remote client.
Local ID	Enter the phase 1 Local ID
Remote ID	Enter the phase 1 Remote ID
Lifetime	Enter the phase 1 lifetime (between 3600 and 86400 seconds)
Authentication	Choose the phase 1 authentication
Encryption	Choose the phase 1 encryption
Key Management	Choose the phase 1 group key management
Enable Multiple Proposals	Check to allow the EtherLINQ to offer multiple combinations of authentication, encryption and key management to the remote VPN client. Selecting this option can overcome mismatches between the VPN devices if the remote VPN client also supports multiple proposals.

NOTE: For IKEv1, if the Local and Remote ID values are blank, the EtherLINQ uses its own public WAN IP address as the Local ID and the IP address of the remote VPN client as the Remote ID. If the remote client has a dynamic IP address, or you use a FQDN to reference it, or it is behind a NAT firewall, Local and Remote ID values may be required on both VPN end-points.

For IKEv2, Local and Remote ID values are required.

Phase 2

Lifetime	Enter the phase 2 lifetime (between 3600 and 86400 seconds)
Authentication	Choose the phase 2 authentication
Encryption	Choose the phase 2 encryption
Key Management (PFS)	Choose the phase 2 group key management. This setting is also known as Perfect Forward Secrecy.
Enable Multiple Proposals	Check to allow the EtherLINQ to offer multiple combinations of authentication, encryption and key management to the remote VPN client. Selecting this option can overcome mismatches between the VPN devices if the remote VPN client also supports multiple proposals.

10.4 IPsec Tunnel Status

IPsec VPN Settings							
Enable IPsec	Yes ▾	Enable/Disable IPsec VPN features					
IPsec Log Level	Normal ▾	Changing log level will reset all tunnels					
#	Connection Name	Initiate	Remote Gateway	Remote Subnet / Mask	Phase 1	Phase 2	Action
1	Remote-Users	Manual	Remote Clients	Any			Close
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="Refresh"/>							

Figure 34: IPsec VPN Remote User Connection Status

Multiple Net-to-Net and Remote User rules may be active at the same time to support both fixed and mobile VPN end-points.

IPsec VPN Settings							
Enable IPsec	Yes ▾	Enable/Disable IPsec VPN features					
IPsec Log Level	Normal ▾	Changing log level will reset all tunnels					
#	Connection Name	Initiate	Remote Gateway	Remote Subnet / Mask	Phase 1	Phase 2	Action
1	Main-Office-VPN	Auto	main-office.prxd.com	10.0.0.0/255.0.0.0			Close
2	Remote-Users	Manual	Remote Clients	Any			Close
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="Refresh"/>							

Figure 35: IPSec VPN Connection Status

CHAPTER 11: GPS TAB

On GPS equipped EtherLINQ models, the **GPS** tab configures the GPS receiver and determines how GPS data is made available to remote GPS applications. The EtherLINQ's GPS receiver outputs data in National Marine Electronics Association (NMEA) 0183 standard format (datum WGS-84). GPS data is derived solely from GPS satellites – an external GPS antenna is required. Positional data is updated once per second (1 Hz).

11.1 GPS Setup

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
GPS Settings										
Enable GPS		Yes ▾							Enable/Disable GPS features	
NMEA Sentence Output		<input checked="" type="checkbox"/> \$GPGLL (Geo. Position - Latitude, Longitude) <input checked="" type="checkbox"/> \$GPGGA (GPS Position Fix Data) <input checked="" type="checkbox"/> \$GPGSA (GPS DOPS and Active Satellites) <input type="checkbox"/> \$GPGST (GNSS Pseudorange Noise Statistics) <input checked="" type="checkbox"/> \$GPGSV (GPS Satellites in View) <input checked="" type="checkbox"/> \$GPRMC (Rec. Min Specific GNSS Data) <input checked="" type="checkbox"/> \$GPVTG (Course Over Ground & Speed) <input type="checkbox"/> \$GNGNS (GNSS fix data) <input type="checkbox"/> \$GNGSA (GNSS DOPS and Active Satellites) <input type="checkbox"/> \$GLGSV (GNSS Satellites in View)							Select NMEA sentence types to output	
Prepend TAG		<input type="text"/> (15 char max)							TAG Block string prepended to NMEA sentences	

Figure 36: GPS Setup

Enable GPS	The GPS feature can be enabled or disabled. NOTE: It is possible to completely remove the GPS functionality from the EtherLINQ. See <i>Section 14.1.2 Activating & Deactivating Features</i> .
NMEA Sentence Output	Select the combination of NMEA sentences to be output. Available NMEA sentences may vary by EtherLINQ model.
Prepend TAG	Up to 15 characters can be prepended to each NMEA sentence to uniquely identify the data stream from this EtherLINQ.

11.2 GPS Data Streams

The EtherLINQ can simultaneously make GPS data available on a specified port so that remote GPS applications can retrieve the data stream and the EtherLINQ can push the GPS data stream to a specific remote host device for further processing.

GPS Data Streams		
Publish Data on	TCP ▾ port # 10110	Make GPS data available on indicated port
Send Data to	Host/IP Address: <input type="text"/> on TCP ▾ port # 10110	Push GPS data to indicated destination

Figure 37: GPS Data Streams

Publish Data on	Select the protocol (TCP or UDP) and the port number that will be used to serve the GPS data
Send Data to	Enter the remote host IP address or FQDN, protocol and port of where the EtherLINQ should send the GPS data stream. The host may be on either the LAN or WAN interface.

CHAPTER 12: USB TAB

The **USB** tab configures the EtherLINQ's two embedded USB servers on models with these features enabled:

1. USB Webcam Server
2. USB Serial Device Server

The USB Webcam Server enables the EtherLINQ to use inexpensive USB web cameras to provide basic remote video viewing capabilities. Most USB webcams are supported.

The USB Serial Device Server enables the EtherLINQ to interface with legacy serial devices to make them available over the WAN.

12.1 USB Webcam Setup

The USB Webcam Server uses a standard inexpensive USB web camera to take a series of MJPEG images and stream them on to a designated TCP port. The USB Webcam Server can be used to add video observation capabilities to an application environment without a significant hardware investment or using an Ethernet port.

NOTE: The USB Webcam Server is not intended as a substitute for high-resolution or advanced capability IP network cameras for video surveillance or similar applications. IP cameras can be connected to the EtherLINQ's LAN Ethernet port or WiFi Access Point.

The USB Webcam Server does not support video compression and is best used with low resolution images at relatively low frame rates. Audio, Pan/Tilt/Zoom and other advanced camera functions are not supported.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
USB Webcam Settings										
Enable Webcam Server	Yes ▾		Enable/Disable USB Webcam Server							
Username	admin		Live View access username							
Password	1234		Live View access password							
Video Stream	8081		Output video stream on TCP port #							
Live View HTTP Port	8082		Use TCP port # to access Live View							
Open Live View	Live View		View and control live webcam stream							

Figure 38: Webcam Server Setup

Enable Webcam Server	The Webcam Server feature can be enabled or disabled. NOTE: It is possible to completely remove the Webcam Server functionality from the EtherLINQ. See <i>Section 14.1.2 Activating & Deactivating Features</i> .
Username	Enter the username required for authentication to the live video stream. This username can be different from the EtherLINQ's configuration username.
Password	Enter the password required for authentication to the live video stream. This password can be different from the EtherLINQ's configuration password.
Video Stream	Enter the TCP port number that will be used to output the live video stream. Third-party viewing applications such as VLC should use this port number.
Live View HTTP Port	Enter the TCP port number that the EtherLINQ will use to serve up its Live View video monitor application (see below)
Open Live View	Clicking this button will open the Live View application (Figure 39) in a new browser window

The Live View application provides a convenient web-based tool for viewing and customizing the USB Webcam video stream. It also provides basic motion detection capabilities. Live View can be used locally or remotely (if your WAN service includes inbound connections). The video stream can also be viewed on any MJPEG capable viewer such as VLC, AnyCam, etc. including SmartPhone viewer apps. These applications may provide additional functionality such as recording.

NOTE: Enabling the USB Webcam Server automatically opens the Video Stream and Live View ports to the WAN and forwards those ports to the Webcam Server. No other port-forwarding/firewall rules are required.




Figure 39: USB Webcam Live View Window

Resolution	Camera resolution (image size). Larger images require more bandwidth and data.
Image Quality	Quality of the JPEG images in percent
Image Rotation	Rotate image 0, 90, 180 or 270 degrees
Motion Detection	Detect changes in pixel between images. Low/Medium/High sensitivity. High sensitivity detects motion based on fewer changed pixels.
Motion Highlight	Indicate changed pixels with a red or white box or cross
Image Overlays	Place the current Date & Time in the lower right corner of the image. Place the System Name in the lower left corner of the image. Specify the text size.
Pause Video Stream	Live View will stop streaming images after the set amount of time. This prevents excessive data usage if the Live View window is left open.

12.2 USB Serial Device Server Setup

USB Serial Port Settings		
Enable Serial Server	Yes ▾	Enable/Disable USB Serial Device Server
TCP	5001	Enter the TCP port # to use for serial communicatons
Baud Rate	4800 ▾	Select the Baud rate
Parity	None ▾	Select the Parity setting
Data Bits	8 ▾	Select the data packet size
Stop Bits	1 ▾	Select the number of stop bits

Figure 40: Serial Device Server Setup

Enable Serial Server	The Serial Server feature can be enabled or disabled. NOTE: It is possible to completely remove the Serial Server functionality from the EtherLINQ. See <i>Section 14.1.2 Activating & Deactivating Features</i> .
TCP	TCP port number where serial data will be streamed. Remote devices must listen on this port.
Baud Rate	Baud rate of incoming data from the serial port
Parity	Parity of the incoming serial data
Data Bits	Number of data bits per byte of serial data
Stop Bits	Number stop bits per byte of serial data

With an RS-232 to USB adapter, the EtherLINQ can be used to stream data from a serial port on a legacy device to a computer on the Internet for collection and analysis; the serial port might also be used for remote programming or diagnostics of equipment. USB devices that can directly emulate a standard serial port can be connected directly. Applications wishing to access the remote serial data stream may need to install virtual serial port drivers to translate the TCP data stream into the serial format needed by the application. See the Proxicast web site for a list of known compatible serial interface adapters and drivers.

CHAPTER 13: ADVANCED TAB

The **Advanced** tab is a collection of functions that control how the EtherLINQ is accessed and other system capabilities:

1. Device Access
2. Scheduled Reboot
3. Dynamic DNS
4. Syslog
5. Advanced Configuration

13.1 Device Access

Device Access configures the System Name, management ports and restrictions for accessing the EtherLINQ.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
Device Access										
System Name		EtherLINQ-001B3910CAE!		Descriptive name for this device						
HTTP Config Port		8080		HTTP port for configuration. Enter 0 to disable.						
HTTPS (SSL) Config Port		4443		HTTPS (SSL) port for configuration. Enter 0 to disable.						
HTTP/S Config Password		1234		HTTP/S password for configuration						
Remote Device Management		No ▾		Allow access to configuration settings via WAN						
Permitted WAN IP Addresses				Comma separated list of IP addresses allowed to make WAN connections. Blank permits all IPs.						

Figure 41: Device Access Setup

System Name	String which identifies this specific EtherLINQ device. Value is displayed on the upper right of the EtherLINQ management pages.
HTTP Config Port	TCP port number used to access the EtherLINQ's configuration screens via HTTP. Default is port 8080.
HTTPS (SSL) Config Port	TCP port number used to access the EtherLINQ's configuration screens via HTTPS. Default is port 4443.
HTTP/S Config Password	Password required for authenticating to the EtherLINQ's management interface via HTTP or HTTPS. Default is 1234.
Remote Device	Enable/Disable access to the EtherLINQ's management pages from WAN devices.

Management	<p>NOTE 1:Remote Device Management is DISABLED by default as a security measure to protect the EtherLINQ from Internet threats. Remote Device Management must be enabled in order to manage the EtherLINQ remotely over the Internet. The EtherLINQ configuration system is always available over the LAN interface.</p> <p>NOTE 2:Enabling Remote Device Management requires that the EtherLINQ's default password to be changed.</p>
Permitted WAN IP Addresses	If Remote Device Management is enabled, access to the EtherLINQ's management interface can be restricted to specific remote IP addresses. Enter a comma delimited list of permitted IP addresses.

13.2 Scheduled Reboot

The EtherLINQ can reboot itself under various conditions.

Scheduled Reboot		
Reboot on Disconnect	No ▼	Reboot EtherLINQ when the WAN connection drops
Reboot Interval	<input type="text"/>	Every 5 ~ 43200 minutes (blank to disable)
Daily Reboot Time	NONE ▼ UTC	Time of Day to Reboot

Figure 42: Schedule Reboot Setup

Reboot on Disconnect	The EtherLINQ can reboot whenever it detects that a WAN interface is down. This can help re-establish WAN connections in some instances.
Reboot Interval	Reboots can occur on a countdown timer from the previous reboot. Use this setting to reboot at regular intervals from 5 minutes to 43,200 minutes (30 days).
Daily Reboot Time	The EtherLINQ can reboot every day at a selected time. NOTE: Reboot time is always specified in UTC.

Note: The Interval and Daily reboot timers can be combined. For example, the EtherLINQ can restart every 8 hours and always at 1 AM UTC so that there is at least one known reboot time. If the Daily Timer is used, do not set the Interval timer greater than 1440 minutes (24 hours).

13.3 Dynamic DNS (DDNS)

DDNS (Dynamic Domain Name Service) allows an “internet domain name” to be assigned to an EtherLINQ which has a public WAN IP address. This makes it possible for other Internet devices to connect to the EtherLINQ without needing to use the WAN IP address.

DDNS is useful when the EtherLINQ is used in IP Pass-Through or NAT Router Modes. It allows remote Internet users to connect to LAN device(s) by using a domain name, rather than an IP address. For example, assume that you wish to remotely access a web server embedded in one of your LAN devices, but the EtherLINQ obtains a different IP address from your ISP every time it connects to the Internet. In this case, DDNS allows users to connect to the web server through a fixed domain name without regard for the changing IP address of the WAN connection.

NOTE : DDNS only works if the WAN port receives a public (Internet routable) IP address and the ISP does not block in-bound initiated connections. Many cellular service providers are now assigning private or blocked IP addresses by default. Contact your service provider regarding the availability of a public IP address.

NOTE : As a service to its customers, Proxycast operates a Dynamic DNS service which is automatically updated each time an EtherLINQ WAN IP changes. The DDNS host name is the serial number of the EtherLINQ in the “etherlinq.net” domain. For example: 001B3910CAE9.etherlinq.net.

Additionally, the EtherLINQ supports custom DDNS hostname via the DynDNS and No-IP web services. Contact these organizations to create an account and hostname.

Dynamic DNS Settings		
DDNS Provider	DynDNS ▼	Select Dynamic your DNS service provider
Hostname	<input type="text"/>	Enter your Dynamic DNS Hostname, e.g. myhost.dyndns.com
Username	<input type="text"/>	Enter your Dynamic DNS account Username
Password	<input type="text"/>	Enter your Dynamic DNS account Password
Enable Default DNS Hostname	Yes ▼	Enable/Disable 001B3910CAE9.etherlinq.net DNS updates

Figure 43: Dynamic DNS Setup

DDNS Provider	DynDNS and No-IP services are supported.
Hostname	Enter the full-qualified domain name (FQDN) for this specific EtherLINQ as

	defined in your account at the DDNS service provider. Enter the entire domain name, e.g.: myrouter.mydomain.com This hostname must be defined within your DDNS service provider account before it can be updated by the EtherLINQ. The hostname must match exactly on both the DDNS account and this field.
User Name	Enter the username for your DDNS service provider account. We recommend avoiding special characters (#, \$, &, @, etc) in your username.
Enable Default DNS Hostname	Disabling this feature prevents the EtherLINQ from attempting to update Proxycast's DNS server.

The EtherLINQ updates the DDNS service whenever the active WAN IP address changes due to WAN Fail-Over or renewal of the WAN IP address.

13.4 Syslog Server

Syslog is a standard mechanism for transmitting and storing system log information from a device to a remote server. The EtherLINQ can send its system event log to another system which is running a Syslog server. The Syslog server can alert administrators of events and store event logs over long periods of time.

External Syslog Server Settings		
Enable External Syslog	No ▾	Enable/Disable remote syslog communications
Syslog Server	<input type="text"/>	DNS name or IP address of syslog server
Protocol	UDP ▾	Remote syslog communication protocol
Port	514	Syslog server's TCP or UDP listening port

Figure 44: Syslog Server Setup

Enable External Syslog	Enable/Disable the Syslog feature
Syslog Server	IP address or fully qualified domain name of the Syslog server which will receive event messages
Protocol	IP protocol (TCP or UDP) that the Syslog server expects messages to use
Remote Port	Port number that the remote Syslog server is listening on (default is UDP514)

13.5 Additional Configuration

The Additional Configuration Settings field is used to send advanced configuration parameters to the EtherLINQ which are not available in the graphical user interface. Settings entered into the Additional Configuration Settings field are saved as part of the EtherLINQ's overall configuration. Refer to the TechNote *ELTN0001: EtherLINQ Command Reference* for a list of available configuration parameters and values.



Figure 45: Additional Configuration Setup

The EtherLINQ generates the necessary basic settings on each save; additional commands are used mostly for debugging and technical support issues. However, several functions may be useful in certain common situations.

DISABLERESET=1	Prevents the hardware Reset button from performing a reset to factory settings when pressed for 10 seconds. The 2 second Configuration Mode press is still permitted. Useful to prevent accidental or unwanted configuration resets.
LOGTOSD=1	Writes the System Event Log to the microSD card; entries are appended to the file <i>systemname.log</i> at the root of the microSD card. Allows event log entries to be recorded across system restarts. Remove the drive to examine the log file with a PC. Log files limited to 64 MB in size.
LOGTOUSB=1	Writes the System Event Log to a USB flash memory drive; entries are appended to the file <i>systemname.log</i> at the root of the USB drive. Allows event log entries to be recorded across system restarts. Remove the drive to examine the log file in with a PC. Log files limited to 64 MB in size.
DELTACSQ=n where n = 0 to 100 default = 10	Log changes in Signal Quality that exceed n% of the prior value. Set higher to suppress nuisance log entries when signal strength changes dramatically; set lower to monitor signal level changes more closely.

CHAPTER 14: ADMIN TAB

The **Admin** tab contains a collection of tools for administering and maintaining the EtherLINQ including firmware updates, configuration backup/restore and diagnostics.

14.1 Device Maintenance

This section allows users to manually upgrade EtherLINQ firmware, view and install SSL certificates and activate/deactivate optional EtherLINQ features. Each button leads to additional screens to complete the action.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
Device Maintenance										
Update EtherLINQ Firmware		Update								
Import SSL Certificate		Import								
View SSL Certificate		View								
Activate Features		Install								

Figure 46: Device Maintenance Functions

Update EtherLINQ Firmware	Begins the interactive process of manually installing new EtherLINQ firmware. See <i>Section Chapter 1:A.6 Updating EtherLINQ Firmware</i> for more information.
Import SSL Certificate	The EtherLINQ contains a self-signed X.509 SSL certificate that is used by the internal HTTPS server. Users may import their own SSL certificates to replace the self-signed certificate. See <i>Section 14.1.1 SSL Certificate Format</i> .
View SSL Certificate	Displays the decoded contents of the currently active EtherLINQ SSL certificate
Activate Features	The EtherLINQ has a number of features that can be installed or removed. Certain EtherLINQ models may include one or more optional features; other features may require a separate license. See <i>Section 14.1.2 Activating & Deactivating Features</i> .

14.1.1 SSL Certificate Format

SSL certificates to be imported into the EtherLINQ must be in PEM format and consist of the device certificate, any intermediate certificates between the device and a browser-trusted Certificate Authority, followed by the private key for the device certificate, all appended together in a single text file.

```

-----BEGIN CERTIFICATE-----
MIIGCDCCA/CgAwIBAgIQKy5u6t11NmWUim7bo3yMBzANBgkqhkiG9w0BAQwFADCB
. . .
+AzxAeKCINT+b72x
-----END CERTIFICATE-----
-----BEGIN CERTIFICATE-----
MIIFdDCCBFygAwIBAgIQJ2buVutJ846r13Ci/ITeIjANBgkqhkiG9w0BAQwFADBv
. . .
pu/xO28QOG8=
-----END CERTIFICATE-----
-----BEGIN CERTIFICATE-----
MIIFYDCCBEigAwIBAgIQFut20fVLtx4nwKSkqbG2kjANBgkqhkiG9w0BAQsFADCB
. . .
H6uv7JYa63uvx8imblP3FsrXcPOPayb0SRln6lrtfUoC0cJy
-----END CERTIFICATE-----
-----BEGIN RSA PRIVATE KEY-----
MIIEpAIBAAKCAQEAvR1xm2u7Yd9uKJ3JYWjGSWb0qbQd1X3pWWS6ap8WC6+dQ11e
. . .
aQDd9AdM+LPoFCcgVfaahj0gCQWYvYH2dC0i3zzp+MHQLCCq/1cGsw==
-----END RSA PRIVATE KEY-----

```

Figure 47: SSL Certificate Example (abridged)

14.1.2 Activating & Deactivating Features

Many of the EtherLINQ's non-core features can be selectively enabled or disabled as needed. For example, to prevent unauthorized use of WiFi, the entire WiFi system can be deactivated. Certain other features may not be included in a specific EtherLINQ model, but can be licensed and activated separately.

Click the **Install** button to view or change the EtherLINQ's active features (Figure 48).




Figure 48: Feature Activation

EtherLINQ features are authorized by Activation Codes which are unique to each feature/EtherLINQ serial number pair. To install a feature, highlight an Available Feature and enter its activation code. To remove a feature, highlight an Installed Feature and click the **Remove** button. The EtherLINQ will display the activation code for this feature (Figure 49) – make note of the activation code in case you need to re-activate the feature in the future. Also, if the EtherLINQ is reset to factory defaults, any activated features will be lost and must be reactivated.




Figure 49: Feature Activation Code

14.2 Configuration Settings

The EtherLINQ's configuration settings can be saved to an external file and later restored. This assists with backups should the EtherLINQ be reset and can also be used to “clone” settings from one EtherLINQ to another.

Configuration Settings	
Export Settings to File	<input type="button" value="Export"/>
Import Settings from File	<input type="button" value="Choose File"/> No file chosen <input type="button" value="Import"/>
Reset to Factory Default Settings	<input type="button" value="Reset"/>

Figure 50: Save / Restore / Reset Configuration Settings

Export Settings to File	Click to save the EtherLINQ's current settings to a file on your PC. Do not edit this file or it will not be able to be used to re-import the settings.
Import Settings from File	Configuration settings saved to a file by the Export process can be imported into any EtherLINQ. We recommend only importing configurations saved using the same EtherLINQ firmware revision. NOTE: Importing a saved configuration file will cause the EtherLINQ to reboot and apply the new settings.
Reset to Factory Default Settings	Returns the EtherLINQ to the original factory default settings; any custom settings will be lost. This button performs the same function as pressing the physical Reset button on the EtherLINQ. See <i>Section A.8 EtherLINQ Default Settings</i> .

Configuration settings may also be imported by saving the desired settings on an EtherLINQ, then using the **Export Settings to File** procedure above. Rename the output file to *EtherLINQ.cfg* and copy that file to the root of a USB drive. Insert the USB drive into a different EtherLINQ, power on that EtherLINQ and wait for the OS LED to stop flashing, then power off the EtherLINQ. When the second EtherLINQ is powered on again, it will have the settings from *EtherLINQ.cfg* file. This technique is useful for quickly cloning a large number of EtherLINQs.

14.3 Tools

The Tools section includes several functions for checking WAN connectivity and other EtherLINQ operating state information.

Tools	
Ping / Trace Route	<input type="text"/> <input type="button" value="Ping"/> <input type="button" value="Trace"/>
Dynamic Tables	<input type="button" value="DHCP Leases"/> <input type="button" value="ARP Table"/> <input type="button" value="Route Table"/>
Reboot Now	<input type="button" value="Reboot"/>

Figure 51: Tools

Ping / Trace Route	<p>Enter an IP address or FQDN in the field.</p> <p>The Ping button sends 4 ICMP packets to the indicated destination.</p> <p>The Trace button initiates a Trace Route command to the destination.</p> <p>Results are displayed in an overlay window.</p>
Dynamic Tables	<p>The DHCP Leases button shows the devices to which the EtherLINQ has issued an IP address to via a DHCP request.</p> <p>The ARP Table button displays a list of external IP and MAC addresses that have recently communicated with the EtherLINQ.</p> <p>The Route Table button displays the current WAN routing information.</p>
Reboot Now	This button causes the EtherLINQ to restart

14.4 Debug Information

The buttons in this section provide detailed information about the internal operation of the EtherLINQ.

Debug Information	
Modem Module Details	View
Device Debug	View
Export Diagnostic Info	Export

Figure 52: Debug Functions


Modem Module Details	Displays a screen with information about the EtherLINQ's internal LTE modem module. This information can be helpful when troubleshooting connectivity issues.
Device Debug	Displays a summary of the EtherLINQ's diagnostic and status information
Export Diagnostic Info	When requested by Proxicast Technical Support, use this button to produce a file on your PC with detailed diagnostic and log information. Forward the saved file to Proxicast for analysis.

CHAPTER 15: LOG TAB

The **Log** tab displays the EtherLINQ's system event log history which records various events that have occurred since the last EtherLINQ reboot. The log is displayed in reverse chronological order (newest entries at the top).

The EtherLINQ has a limited amount of space available for log events – the oldest events are overwritten when the log is full. See Sections 13.4 - *Syslog Server* and 13.5: *Additional Configuration* regarding techniques for storing system log events over longer periods of time. The log timestamps are always in UTC.

The **Refresh** button updates the log display with the latest events. The **Clear** button erases the entire system log. The **Copy to Clipboard** button copies the current syslog to the PC's clipboard for use in other applications.



The screenshot shows the 'Log' tab of the EtherLINQ interface. At the top, there are navigation tabs: Status, Mode, LTE, WAN, WiFi, VPN, GPS, USB, Advanced, Admin, and Log. Below these is the 'EtherLINQ System Event Log' section, which includes three buttons: Refresh, Clear, and Copy to Clipboard. The main area displays a list of system events in reverse chronological order, starting from the most recent at the top. Each log entry includes a timestamp (e.g., 'Thu Jun 28 06:34:58 2018'), a severity level (e.g., 'user.notice'), a source (e.g., 'root:'), and a message (e.g., 'System Name EtherLINQ-001B3910CAE9').

```

Thu Jun 28 06:34:58 2018 user.notice root: System Name EtherLINQ-001B3910CAE9
Thu Jun 28 06:34:58 2018 user.notice procd: fsck.fat 4.0 (2016-05-06)
Thu Jun 28 06:34:56 2018 user.notice root: Web server started
Thu Jun 28 06:34:53 2018 user.notice root: Current configuration PM=nat TAB=USB ROD=0 NP=AUTO MOD_APN=m
Thu Jun 28 06:34:53 2018 user.notice root: MAC address 001B3910CAE9
Thu Jun 28 06:34:53 2018 user.notice root: Firmware version 5.0.11
Thu Jun 28 06:34:52 2018 user.notice root: Current network is Verizon, old network is Verizon
Thu Jun 28 06:34:52 2018 user.notice procd: root: Current network is Verizon, old network is Verizon
Thu Jun 28 06:34:52 2018 user.notice root: !!! IMSI RESULTS: MCC=311 MNC=480
Thu Jun 28 06:34:52 2018 user.notice procd: root: !!! IMSI RESULTS: MCC=311 MNC=480
Thu Jun 28 06:34:52 2018 user.notice root: QMI connection started
Thu Jun 28 06:34:51 2018 user.notice root: QMI Returned IP address is 166.246.222.80 DNS1 198.224.152.1
Thu Jun 28 06:34:51 2018 user.notice root: MYIP 166.246.222.80 CGP
Thu Jun 28 06:34:50 2018 user.notice root: ALL INTERFACES ARE DOWN
Thu Jun 28 06:34:49 2018 user.notice root: Network type changed from UNKNOWN to LTE
Thu Jun 28 06:34:49 2018 user.notice root: Signal level changed from 0% to 48%
Thu Jun 28 06:34:49 2018 user.notice root: QMI connection not established, we will not ping on wwan0
Thu Jun 28 06:34:48 2018 user.notice procd: sh: write error: Broken pipe
Thu Jun 28 06:34:47 2018 user.notice procd: /dev/mmcblkOp1: 5 files, 139/488672 clusters
Thu Jun 28 06:34:47 2018 user.notice procd: Performing changes.
Thu Jun 28 06:34:47 2018 user.notice procd: Automatically removing dirty bit.
Thu Jun 28 06:34:47 2018 user.notice procd: 0x41: Dirty bit is set. Fs was not properly unmounted and s
Thu Jun 28 06:34:47 2018 user.notice procd: fsck.fat 4.0 (2016-05-06)
Thu Jun 28 06:34:46 2018 user.notice root: QMI connection attempt 1 to APN mw01.vzwstatic
Thu Jun 28 06:34:46 2018 kern.notice kernel: [ 57.680000] random: nonblocking pool is initialized
Thu Jun 28 06:34:44 2018 user.notice procd: CP437: Success
Thu Jun 28 06:34:43 2018 user.notice root: Restarting CSQ monitoring
Thu Jun 28 06:34:43 2018 user.notice root: Signal level on boot is 48%
Thu Jun 28 06:34:43 2018 user.notice procd:
Thu Jun 28 06:34:43 2018 user.info php-cli: WiFi configuration changed
Thu Jun 28 06:34:42 2018 daemon.notice netifd: Network device 'ra0' link is up
Thu Jun 28 06:34:41 2018 kern.warn kernel: [ 53.030000] 0x1300 = 00064380
Thu Jun 28 06:34:41 2018 kern.warn kernel: [ 53.030000]
  
```

Figure 53: System Log

CHAPTER 16: CONFIGURATION MODE

Configuration Mode is a mechanism for accessing the EtherLINQ via its LAN Ethernet port when it is operating in IP Pass-Through or Virtual Cable mode and thus does not have an assigned IP address. Configuration Mode can also be used when the EtherLINQ is in NAT Router mode and the LAN IP address is unknown.

To access Configuration Mode, press and hold the Reset button on the EtherLINQ's front panel for 2 seconds, until the OS LED begins to flash rapidly, then release the button. The OS LED will continue to flash as long as Configuration Mode is active.

When activated, Configuration Mode forces the EtherLINQ's LAN IP address to 192.168.1.1 and the HTTP port to 8080 (HTTPS=4443). The system password is not affected. Access the EtherLINQ at <http://192.168.1.1:8080>

Name: EtherLINQ-001B3911656C
Serial: 001B3911656C

Configuration Mode - Reboot to Exit

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log
Device Status										
EtherLINQ Model	EL-001 / LE910-SVG		Cellular Ethernet Modem/Router							
Firmware Version	5.1.2		EtherLINQ software release		<input type="button" value="Check for updates"/>					
System Uptime	1w 1d 09:02:33		Time since last restart							

Figure 54: Configuration Mode

Configuration Mode is indicated by a red banner across the EtherLINQ's web page header (Figure 54). Any settings may be modified while in Configuration Mode. To exit Configuration Mode and return to regular EtherLINQ operations, a system reboot is required. Press the **Reboot** button in the banner or power-cycle the EtherLINQ.

APPENDIX

A.1 Common Tasks

HOW TO	WHERE	ACTION
Change the LAN IP Address	Mode Tab	Enter the IP address to be assigned to the EtherLINQ and select the subnet mask for the LAN. The DHCP Server will automatically adjust to the new subnet.
Configure the LTE APN	LTE Tab	Enter the Access Point Name (APN) assigned to your SIM. Also configure LTE Keep-Alive settings.
Change the WiFi Password	WiFi Tab	Configures the Access Point's SSID and security settings.
Forward Ports to LAN Devices	Mode Tab > NAT Router Mode	Enter up to 10 port-forward / translation rules.
Set up a VPN	VPN Tab	Enable IPSec and Add new rules for each VPN tunnel.
Configure WAN Fail-Over	WAN Tab	Set WAN priority, fail-over and connection Keep-Alive settings.
Restart Periodically	Advanced Tab > Scheduled Reboot	Select the frequency for the EtherLINQ to automatically reboot.
Change the System Name	Advanced Tab > Device Access	Enter the System Identification.
Change the EtherLINQ Password	Advanced Tab > Device Access	Passwords are <u>case sensitive</u> . The username cannot be changed from "admin" however multiple users may log in concurrently.
Change the Administration Ports	Advanced Tab > Device Access	HTTP and HTTPS can be assigned to any port or disabled as necessary to avoid port conflicts or increase security.
Backup / Restore Settings	Admin Tab > Configuration Settings	Settings can be saved or restored; EtherLINQ can be reset to factory default settings.
Enable Bridge Mode	Mode Tab > IP Pass-Through	Passes the WAN IP address to first LAN device that requests a DHCP address.
Enable Virtual Cable Mode	Mode Tab > Virtual Cable	Bridges the EtherLINQ to other EtherLINQs and PocketPORTs through any intervening network topology.
Update Firmware	Status Tab > Check For Updates button	Requires an active WAN connection to check the Proxicast server for updates. Manual updates can be installed via the Admin Tab.

A.2 Troubleshooting

PROBLEM	CORRECTIVE ACTION
None of the LEDs turn on	Ensure that the correct power adapter is connected to the EtherLINQ and plugged in to an appropriate power source. If the LEDs still do not turn on, there may be a hardware failure.
Cannot access the EtherLINQ from a PC on the LAN	<p>Check the cable between the computer (or hub/switch) and the EtherLINQ.</p> <p>Check that the corresponding LAN port LED is ON.</p> <p>Enable Configuration Mode.</p> <p>Configure the PC to receive its IP settings via DHCP (automatic assignment).</p> <p>Confirm that any other network interfaces on the PC (such as WiFi) are disabled.</p>
Cannot ping the EtherLINQ from the LAN	<p>If the LAN LEDs are off, check the cable connections.</p> <p>Verify that the IP address and subnet of the EtherLINQ is in the same range as the computers on the LAN and that the EtherLINQ is the default gateway for all LAN devices.</p>
Cannot make (or maintain) a cellular data connection (i.e. no LTE WAN IP address)	<p>Confirm that the SIM has been provisioned & activated with the correct type of Internet access data service.</p> <p>Ensure that the SIM/RUIM card (if required) is properly inserted.</p> <p>Network registration may take several minutes.</p>
Cellular Signal Quality is low	<p>Connections may be unreliable if the signal quality is < 33%.</p> <p>Check that the proper external antenna is securely attached.</p> <p>Use coax extension cables to locate the antennas to a more favorable location.</p> <p>Move the EtherLINQ to a location where the carrier's signal is stronger or use a higher-gain antenna or amplifier.</p>
Cannot get a WAN IP address from the Ethernet WAN ISP	<p>The WAN IP address may not be provided until after the ISP verifies the MAC address. Confirm the verification method used by the ISP.</p> <p>Check the EtherLINQ's connection to the wired WAN (cable/DSL modem).</p> <p>Check whether the Ethernet WAN connection requires a crossover cable.</p>
After pressing RESET, cannot make a WAN connection	The RESET button returns the EtherLINQ to its factory default settings including clearing the LTE APN and WAN parameters.

A.3 Common Carrier Specific Issues

CARRIER	COMMENT
Verizon Wireless 4G/LTE	<p>Verizon Wireless' default APN (vzwinternet) provides only NAT'd IP addresses. This prevents all Internet initiated inbound (remote access) connections from reaching the EtherLINQ.</p> <p>Use the EtherLINQ's IPsec VPN features to make an outbound connection to a VPN server on another network or use Virtual Cable mode to connect to another EtherLINQ; or</p> <p>Purchase a static public IP address from Verizon for an additional fee.</p>
AT&T Wireless	<p>AT&T's default APN (broadband) blocks all packets originating from the Internet. To access the EtherLINQ or other equipment remotely, request that AT&T provide you access to the i2gold APN or another APN which offers mobile terminated data service.</p> <p>Use the EtherLINQ's IPsec VPN features to make an outbound connection to a VPN server on another network or use Virtual Cable mode to connect to another EtherLINQ; or</p> <p>Purchase a static public IP address from AT&T for an additional fee.</p>

Note for Verizon Wireless 4G/LTE Users:

The Verizon Wireless 4G/LTE network assigns private IP addresses by default. In order to use the Verizon Wireless 4G/LTE network for remote access and/or control applications, you must request a "static IP" address from Verizon Wireless or utilize two or more EtherLINQs in Virtual Cable Mode to create an Ethernet bridge between the devices. This is a restriction in how the Verizon Wireless 4G/LTE network is implemented and not a limitation of the EtherLINQ.

Note for AT&T Wireless Users:

The default data service plan from AT&T Wireless assigns private IP addresses to 3G/4G modems. In order to use the AT&T Wireless network for remote access and/or control applications, you must request "mobile terminated data service" from AT&T Wireless in order to obtain a public IP address. Or you may utilize two or more EtherLINQs in Virtual Cable Mode to create an Ethernet bridge between the devices. This is a restriction in how the AT&T Wireless network is implemented and not a limitation of the EtherLINQ.

A.4 Accessing Remote Devices

A common use for the EtherLINQ is to provide remote access to Ethernet equipment from other locations on the Internet. For IP Pass-Through/Bridge Mode and NAT Router Mode, there are three ways to remotely access Ethernet devices connected to the EtherLINQ:

1. Static IP Address
2. EtherLINQ Dynamic DNS Name
3. DynDNS Dynamic DNS Name

When operating in Virtual Cable Mode, remote devices can be accessed by their “private” IP address, just as if they were connected to the local Ethernet network.

A.4.1 Static IP Address

Some cellular and wired Internet service providers offer a “static” or “permanent” public IP address that is assigned to the modem’s SIM card or router’s MAC address. There is often an additional fee for this feature.

If the SIM / MAC has been assigned a static IP address, the EtherLINQ will automatically receive that IP address when it connects to the Internet as long as the proper Access Point Name (APN) has been configured on the LTE tab (see *Chapter 7: LTE TAB*) or the correct WAN settings have been entered in the WAN tab (see *Chapter 8: WAN TAB*). Use the assigned static IP address to access remote Ethernet devices.

A.4.2 EtherLINQ Dynamic DNS

Some Internet service providers assign a random (dynamic) public IP address to the modem every time a new connection is made. This makes it impossible to use the modem’s cellular IP address to access remote devices. The solution is a technique called “dynamic DNS”. With dynamic DNS, a unique “fully qualified domain name” (FQDN) is defined to represent the device with a dynamic IP address. Software on the EtherLINQ then updates the DNS system with the FQDN’s new IP address every time that the IP address changes.

Proxycast maintains a dynamic DNS service which assigns each EtherLINQ a unique and permanent FQDN based on the EtherLINQ’s serial number in the form: *serial#.etherlinq.net* (e.g. 001B39AB12CD.etherlinq.net). The IP address for this DNS name is updated automatically every time the EtherLINQ makes a new WAN connection.

Use this FQDN to access an Ethernet device connected to the EtherLINQ from anywhere on the Internet. For example, if the Ethernet device has an embedded web server, it can be accessed with a web browser by using the address: <http://001B39AB12CD.etherlinq.net>

A.4.3 Dynamic DNS

To define your own (perhaps more memorable) FQDN, the EtherLINQ supports the widely used DynDNS.com and NoIP dynamic DNS services.

Visit DynDNS.com or NoIP.com to create a username, password and hostname. Enter these values into the Dynamic DNS section of the EtherLINQ's configuration page (see *Section 13.3 Dynamic DNS (DDNS)*).

The EtherLINQ will automatically update the Dynamic DNS servers every time a new WAN IP address is assigned. Use the defined hostname (e.g. *myhost.dyndns.com*) to remotely access the Ethernet device attached to the EtherLINQ.

A.4.4 Port Forwarding – NAT Router Mode

To remotely access an Ethernet device when operating the EtherLINQ in NAT Router Mode, the “private” IP address of the Ethernet device must be defined as the Port Forwarding target destination for the NAT Router. See *Section 6.1 NAT Router Mode* for a detailed explanation of the EtherLINQ's port-forwarding/translation features.

A.4.5 Internet Service Provider Restrictions

Some Internet service providers assign “private” IP addresses in the ranges of:

- 10.0.0.0 – 10.255.255.255
- 172.16.0.0 – 172.31.255.255
- 192.168.0.0 – 192.168.255.255

Private IP addresses cannot be used in remote access applications (except in Virtual Cable Mode). Request that the Internet service company provide a routable “public” IP address for your modem. For LTE modems, this may involve changing the Access Point Name (APN) used to connect to the LTE network.

Also, some Internet providers may block certain (or all) “inbound” traffic from the Internet based on the type of service to which you have subscribed. Check with the service provider for more information on options for unblocking inbound connections from the Internet to the EtherLINQ. If you are unable to obtain an unblocked WAN connection, consider using Virtual Cable Mode which uses “outbound” connections to link two sites into a virtual private network.

If you can only obtain a private WAN IP address, do not use the same private subnet for the EtherLINQ LAN networks in NAT Router Mode.

A.5 Cellular Signal Issues

Maximizing Signal Strength

- Place the antenna outside or near a window and as high as possible. Avoid placing in front of “Low-E” glass windows.
- Avoid interference sources such as metal enclosures, lighting fixtures, machinery, and computer/radio equipment.
- Use 2 identical antennas; if using only 1 antenna, connect it to the Main port.
- Keep antenna cabling as short as possible with the minimum number of connectors.

Signal Quality Graph Not Visible

- Use Internet Explorer 9+, Chrome or Firefox
- Enable Javascript support.
- Disable the browser’s prior version compatibility mode.

Signal Strength Varies Significantly

- Signal strength varies over time even for stationary locations due to intermittent interference, cell tower and modem power adjustments and other factors.
- A lower consistent reading is preferred over a highly variable reading that may hit higher peak values.
- The antenna may require a metal ground plane placed beneath it for proper operation.

Signal Strength is Worse with Antenna

- When changing antenna positions, allow 30-60 seconds for the signal strength readings to stabilize.
- Stand at least 2 feet away from the antenna.
- The lower value may be due to the modem reducing its power output to compensate for the higher gain antenna. If the reading indicates a poor signal, the antenna may be in an unfavorable location, not tuned for the cellular carrier’s frequencies or there may be a short in the antenna cable or loose connection.
- The signal loss due to a long cable run or multiple connectors may be offsetting the gain from the antenna.

A.6 Updating EtherLINQ Firmware

There are 3 methods for updating firmware on the EtherLINQ:

1. The **Check For Updates** button
2. Manual update
3. Via USB memory stick

Unless stated otherwise in the firmware release notes, upgrading the EtherLINQ's firmware will NOT erase any saved configuration settings, but a backup of the EtherLINQ's configuration before updating the firmware is highly recommended. Each EtherLINQ firmware release is independent; the latest version can be installed without installing any intervening releases.

NOTE : While the EtherLINQ is installing new firmware, the top row of LEDs will rapidly flash in sequence and the OS LED will turn off. The firmware update process typically takes 6-7 minutes and the EtherLINQ will reboot at the end of the process.

DO NOT POWER OFF THE ETHERLINQ DURING A FIRMWARE UPDATE

Powering off the prematurely may permanently damage the EtherLINQ. Wait for the OS LED to remain on solid before attempting to connect to the EtherLINQ or powering the device off.

A.6.1 Check For Updates Button

On the Status tab, the button next to the current firmware release causes the EtherLINQ to contact a Proxicast server and report if newer firmware is available. For this firmware update option, the EtherLINQ must have an active Internet connection and a FAT32 formatted microSD memory card installed.

Status	Mode	LTE	WAN	WiFi	VPN	GPS	USB	Advanced	Admin	Log	
Device Status											
EtherLINQ Model	EL-001 / LE910-SVG		Cellular Ethernet Modem/Router								
Firmware Version	5.1.1		EtherLINQ software release					<input type="button" value="Check for updates"/>			
System Uptime	06:47:09		Time since last restart								

Figure 55: Check for Firmware Updates

The EtherLINQ will display a results page indicating if newer firmware is available.




Figure 56: Check Updates Status

Please review the **Release Notes** link to see what changes have been incorporated into the latest EtherLINQ firmware. Click the Download & Install button to begin the firmware update process. Depending on the speed of the EtherLINQ's WAN connection, it may take several minutes for the firmware to download.

When downloading is complete, the EtherLINQ will display a confirmation page. The new firmware will be installed on the next reboot of the EtherLINQ.




Figure 57: Check Updates Confirmation

A.6.2 Manual Firmware Update

The EtherLINQ's firmware can also be updated manually by using the firmware **Update** button on the **Admin** tab. For this option, you must first manually download the EtherLINQ firmware from the Proxicast web site. Check <http://support.proxicast.com> for information on the latest EtherLINQ firmware. Both firmware updates and downgrades may be performed using this process.



Figure 58: Manual Firmware Update

The **Update** button presents a dialog page to specify the location of the firmware image file that you downloaded from the Proxicast web site (click the **Choose File** button). EtherLINQ firmware image files are digitally signed to ensure that the firmware being installed is genuine Proxicast firmware. EtherLINQ firmware files have a file extension of “.signed”.




Figure 59: Firmware File Selection

Click the **Upload** button to transfer the firmware file into the EtherLINQ's temporary storage. A confirmation page will display; Click the **Begin Flashing** button to start the actual firmware update process.




Figure 60: Firmware Flashing

A.6.3 Firmware Update via USB

EtherLINQ firmware can also be installed without access to the user interface via a USB memory stick (thumb drive). This allows field personal to perform updates while maintaining security; it is also a convenient way to update many EtherLINQs quickly. For this procedure a FAT32 formatted USB drive is required.

1. Download the desired EtherLINQ firmware image file from <http://support.proxicast.com>
2. Copy the file to the root directory of the USB drive. Only have one version of firmware file at the root.
3. Power off the EtherLINQ and insert the USB drive into the EtherLINQ's USB port
4. Power on the EtherLINQ

After several seconds, the EtherLINQ will detect the firmware file on the USB drive and begin the firmware update process. The top row of LEDs will flash rapidly in sequence. Wait for the EtherLINQ to reboot again and the OS LED to remain on solid. Then remove the USB drive.

NOTE : This process can only be used to install a higher numbered EtherLINQ firmware version; downgrading requires access to the EtherLINQ's user interface. The EtherLINQ will not attempt to reinstall the same firmware version should the USB drive be left in place.

A.7 Specifications

Physical	
Dimensions	4.7 x 5.3 x 1.0 in 120 x 135 x 25 mm (excluding antennas & mounting bracket)
	7.1 x 6.6 x 1.0 in 180 x 168 x 25 mm (including antenna & mounting bracket)
Weight	12 oz (0.34 kg) (excluding antennas & mounting bracket)
	18 oz (0.51 kg) (including antennas & mounting bracket)
Power Specification	9-28 DC input (12 VDC typical)
Power Consumption	< 3W Typical
Operating Temp.	-22 to 140 F (-30~60 C)
Operating Humidity	10%~90%
Chassis	18 ga. Steel. Desktop & Removable Mounting Brackets (included). Kensington Security Slot (lock)
Certifications	EMC: FCC ID: 2AL8JEL-001 FCC Part 15 Class B, CE-EMC Class B, C-Tick Class B, VCCI Class B Safety: CSA International, CE EN60950-1 (UL60950-1, CSA60950-1, EN60950-1, IEC60950-1) – RoHS Compliant
Connectors	
LAN 1	1 LAN auto-negotiating, auto MDI/MDI-X 10/100 Mbps RJ45 Ethernet port
WAN / LAN 2	One auto-negotiating, auto MDI/MDI-X 10/100 Mbps RJ-45 Ethernet port. Software definable as a second LAN port.
USB 2.0	For USB Webcams, serial devices and firmware loading
Power	4-pin Molex Mini-Fit with retention clip
Reset Button	Restores factory default settings & activates Configuration Mode
MicroSD Slot	For internal temporary storage
SIM	Mini SIM (2FF) for LTE modem. SIM size adapters included.
Antennas Connectors	
4G/LTE	2x2 MIMO SMA Female antenna jacks.
	Two 5 dBi paddle style swivel antennas (SMA Male).
WiFi	2x2 MIMO Reverse Polarity SMA (RP-SMA) Female antenna jacks.
	Two 5 dBi rubber duck style swivel 802.11 b/g/n antennas (RP-SMA Male).
GPS (select models)	SMA Female jack.
	Active & Passive antennas supported.
WiFi	
Technology	802.11 b/g/n 300 Mbps max

Operating Mode	Access Point
Security	WPA2-PSK, WPA-PSK, WEP, None
4G/LTE Modem (EtherLINQ model EL-001 / LE910-NAG)	
Module	Telit LE910; FCC ID: RI7LE910NA
Frequency Bands (MHz)	LTE: B17: 700 B5: 850 B4: AWS1700/2100 B2: 1900
Speeds (max)	LTE Category 3: DL up to 100 Mbps UL up to 50 Mbps
4G/LTE Modem (EtherLINQ model EL-001 / LE910-SVG)	
Module	Telit LE910; FCC ID: RI7LE910SV
Frequency Bands (MHz)	LTE: B13: 700 B4: AWS1700/2100
Speeds (max)	LTE Category 3: DL up to 100 Mbps UL up to 50 Mbps
Software Functions	
4G / LTE Features	4G/LTE to WAN Fail-Over and Fall-Back 4G/LTE Keep-Alive Packets Signal Quality History Graph & Statistics 2x MIMO External Antennas Supported
WAN Features	Static & DHCP Address Assignment Assign WAN port to LAN or Disable port WAN to 4G/LTE Fail-Over and Fall-Back WAN Keep-Alive Packets
Networking	LAN DHCP Server WAN Fail-over Detection Limits & Controls Port-Forwarding & Translation IP Pass-Through (Bridge) Mode Virtual Cable Mode (Ethernet over IP) Dynamic DNS (DynDNS, NoIP)

	Permanent DNS Address (serial#.etherlinq.net)
IPSec VPN Features	<p>IPSec Server and Client Modes</p> <p>Site-to-Site & Remote User Access Tunnels</p> <p>Unlimited Simultaneous IPSec Tunnels</p> <p>IKEv1 & IKEv2 Internet Key Exchange</p> <p>DES / 3DES / AES-128 / AES-192 / AES-256 Encryption</p> <p>MD5 / SHA1 / SHA2-256 / SHA2-384 / SHA2-512 Authentication</p> <p>Diffie-Hellmen Groups 1, 2, 5, 14, 15, 16, 17, 18</p> <p>Dead Peer Detection (DPD)</p>
Virtual Cable Mode	<p>Proprietary end-to-end tunneling through any firewall or network topology.</p> <p>Interoperable with Proxicast's PocketPORT devices in Virtual Cable Mode.</p>
Security Features	<p>Network Address Translation & Firewall</p> <p>HTTPS / SSL</p> <p>Feature Restriction</p> <p>Digitally Signed Firmware</p>
Internal Application Servers	Webcam, Serial Device, GPS
System Management	<p>Web-based Management (Local & Remote)</p> <p>Configuration Backup and Restore</p> <p>Firmware Upgrade and Downgrade via web interface or USB drive</p> <p>Syslog Support</p> <p>Real-Time Logging</p> <p>Scheduled System Restarts</p> <p>Ping, Traceroute Utilities</p>

A.8 EtherLINQ Default Settings

LAN IP Address	192.168.1.1 Subnet mask = 255.255.255.0
LAN DHCP Server	Enabled Pool = 192.168.1.33 to .161
HTTP Management Access	admin / 1234 on port 8080
HTTPS Management Access	admin / 1234 on port 4443 using a self-signed SSL certificate
WAN Security	All TCP/UDP ports closed. Remote Management Disabled
Operating Mode	NAT Router
WAN Priority	1. Ethernet WAN 2. LTE WAN
WAN Fall-Back	Check every 60 seconds
Ethernet WAN	DHCP Client Enabled
LTE APN	Carrier Default AT&T = broadband Verizon = vzwinternet T-Mobile = fast.t-mobile.com
LTE & WAN Keep-Alive	ICMP Protocol (ping) to 8.8.8.8 Frequency = every 5 sec; Timeout = 3 sec; Tolerance = 3 consecutive failures
WiFi Access Point	Enabled SSID = EtherLINQ-nnnn where nnnn are the last 4 characters of the serial # WPA2 Password = 8 digit number printed on EtherLINQ label
IPSec VPN	Disabled
GPS Server	Disabled. TCP Port = 10110
USB Webcam Server	Disabled. Video Stream Port = 8081; Live View Port = 8082
USB Serial Device Server	Disabled. TCP Port = 5001
Scheduled Reboot	Disabled
External Syslog	Disabled
DNS Host Name	serial#.etherlinq.net
Reserved Ports	6644 & 9922 are used internally and cannot be forwarded

Press the RESET button for 10 seconds to return the EtherLINQ to these settings.

A.9 Legal Information

Copyright

Copyright © 2007-2019 by Proxicast, LLC.

The contents of this publication may not be reproduced in any part or as a whole, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, magnetic, optical, chemical, photocopying, manual, or otherwise, without the prior written permission of Proxicast, LLC.

Published by Proxicast, LLC. All rights reserved.

Disclaimer

Proxicast does not assume any liability arising out of the application or use of any products, or software described herein. Neither does it convey any license under its patent rights nor the patent rights of others. Proxicast further reserves the right to make changes in any products described herein without notice. This publication is subject to change without notice.

Trademarks

Proxicast is a registered trademark and ProxiOS (Proxicast Network Operating System), EtherLINQ, LAN-Cell, Card-Guard, Cell-Lock, Modem-LOCK, PocketPORT and Cell-Sentry are trademarks of Proxicast, LLC. Other trademarks mentioned in this publication are used for identification purposes only and may be properties of their respective owners.

Open Source Software

This product contains software distributed under one or more of the following open source licenses: Apache 2.0, GNU General Public License (GPL) Versions 2 and 3, GNU Lesser General Public License (LGPL), MIT License, OpenSSL License, PHP 7 License, and strongSwan License. For more information on this software, including licensing terms and your rights to access source code, contact Proxicast.

A.10 FCC Certification

Federal Communications Commission (FCC) Interference Statement

FCC ID: 2AL8JEL-001

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help



FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 27 cm between the radiator and your body. This device and its antennas(s) must not be co-located or operating in conjunction with any other antenna or transmitter except in accordance with FCC multi-transmitter product procedures.

To comply with FCC regulations limiting both maximum RF output power and human exposure to Rf radiation, the maximum WiFi antenna gain must not exceed 7 dBi.

FCC Caution

This device has been designed for the WLAN 2.4 GHz networks. For product available in the USA/Canada market, only channels 1-11 can be operated. Selection of other channels is not possible.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

A.11 Safety and Hazards

Under no circumstances should the device be used in any areas

- (a) where blasting is in progress,
- (b) where explosive atmospheres may be present, or
- (c) that are near (1) medical or life support equipment, or (2) any equipment which may be susceptible to any form of radio interference. In such areas, the device **MUST BE POWERED OFF AT ALL TIMES** (since the device otherwise could transmit signals that might interfere with such equipment).

In addition, under no circumstances should the device be used in any aircraft, regardless of whether the aircraft is on the ground or in flight. In any aircraft, the device **MUST BE POWERED OFF AT ALL TIMES** since the device otherwise could transmit signals that might interfere with various onboard systems on such aircraft.

Furthermore, under no circumstances should the device be used by the driver or operator of any vehicle. Such use of the device will detract from the driver's or operator's control of that vehicle. In some jurisdictions, use of the device while driving or operating a vehicle constitutes a civil and/or criminal offense,

Due to the nature of wireless communications, transmission and reception of data by the device can never be guaranteed, and it is possible that data communicated or transmitted wirelessly may be delayed, corrupted (i.e., contain errors), or totally lost. The device is not intended for, and Proxicast recommends the device not be used in any critical applications where failure to transmit or receive data could result in property damage or loss or personal injury of any kind (including death) to the user or to any other party.

Proxicast expressly disclaims liability for damages of any kind resulting from:

- (a) delays, errors, or losses of any data transmitted or received using the device; or
- (b) any failure of the device to transmit or receive such data.

Purchaser agrees to indemnify Proxicast against any liability or damages caused to third parties as a result of Purchaser's misuse or misapplication of the Proxicast product.

A.12 Proxicast Limited Warranty

Proxicast warrants to the original end user (purchaser) that this product is free from any defects in materials or workmanship for a period of up to one year from the date of purchase. During the warranty period, and upon proof of purchase, should the product have indications of failure due to faulty workmanship and/or materials, Proxicast will, at its discretion, repair or replace the defective products or components without charge for either parts or labor, and to whatever extent it shall deem necessary to restore the product or components to proper operating condition. Any replacement will consist of a new or re-manufactured functionally equivalent product of equal value, and will be solely at the discretion of Proxicast. This warranty shall not apply if the product is modified, misused, tampered with, damaged by an act of God, or subjected to abnormal working conditions.

Note

Repair or replacement, as provided under this warranty, is the exclusive remedy of the purchaser. This warranty is in lieu of all other warranties, express or implied, including any implied warranty of merchantability or fitness for a particular use or purpose. Proxicast shall in no event be held liable for indirect or consequential damages of any kind to the purchaser.

To obtain the services of this warranty, contact Proxicast's Service Center for your Return Material Authorization number (RMA). Products must be returned Postage Prepaid. It is recommended that the unit be insured when shipped. Any returned products without proof of purchase or those with an out-dated warranty will be repaired or replaced (at the discretion of Proxicast) and the customer will be billed for parts and labor. All repaired or replaced products will be shipped by Proxicast to the corresponding return address, Postage Paid. This warranty gives you specific legal rights, and you may also have other rights that vary from country to country.

A.13 Customer Support

Online Web Support

Please refer to support.proxicast.com for additional support documentation and access to our Knowledgebase which contains many resources such as TechNotes, Frequently Asked Questions, sample configurations and firmware updates.

E-Mail Support

Support E-mail: support@proxicast.com

Please provide the following information when you contact customer support:

- Product model and serial number.
- Current firmware version running on the device
- Date that you received your device.
- Brief description of the problem and the steps you took to solve it.

Corporate Headquarters (Worldwide Customer Support)

- Sales E-mail: sales@proxicast.com
- Telephone: 877-777-7694 (412-213-0018)
- Fax: 412-492-9386
- Web Site: www.proxicast.com
- Regular Mail & RMA Shipments:
Proxicast, LLC 312 Sunnyfield Drive, Suite 200 Glenshaw, PA 15116-1936 USA

Return Merchandise Authorizations (RMA)

If you need to return a product for service, you must contact Customer Support and request an RMA Number. Returns will not be accepted without an RMA Number on the outside of the shipment.

Please return only the main product unit (no accessories) unless otherwise directed by Customer Support.

Securely pack and insure the product. Return shipping costs are the responsibility of the customer.

K	Q
Keep-Alive.....27, 30	Quick Setup 10
Kensington Lock.....4	LAN Configuration 12
	Password..... 11
	Remote Devices 13
	WAN/LTE Modem Configuration..... 10
	WiFi Configuration..... 12
	R
	Rear Panel4
	Reboot51
	Remote Access50, 65
	Remote Device Management.....50
	Remote User VPN.....39
	Reset.....75
	Reset Button3
	RMA81
	RS-232.....49
	RSCP17
	RSRP17
	RSRQ.....17
	RSSI.....16
	S
	Safety Warnings..... vii
	Scheduled Reboot.....51
	SD Card3
	Serial Devices46
	SIM..... 3, 5, 10, 27, 63, 72
	Site-to-Site VPN.....36
	Specifications72
	SSID.....32
	SSL Certificate55
	Static IP.....29, 34, 64, 65
	Status Tab14
	Support81
L	
LEDs3	
Live View47	
Log Tab60	
Login6	
LTE Tab27	
M	
Menus8	
MicroSD3, 72	
MJPEG.....46	
Mode Tab18	
Modem27, 63, 64, 67	
Modem Signal Quality Graph16	
Motion Detection47	
MTU27, 29	
N	
NAT Router.....19	
Network Address Translation (NAT)19	
NMEA.....44	
No-IP52	
P	
Password6	
Ping.....27, 30, 59	
PocketPORT25	
Port Forwarding.....19	
Port Translation19	
Power4, 72	
Pre-Shared Key.....37, 41	

Switchboard Server.....	25	Virtual Cable Mode.....	24		
Syslog Server.....	53	VLC.....	47		
T					
Trace Route.....	59	VPN			
Troubleshooting.....	63	Net-to-Net.....	36		
U				Remote User.....	39
Updating Firmware.....	68	VPN Tab.....	34		
USB Port.....	4, 72	W			
USB Serial Device Server.....	46	WAN Fail-Over.....	30		
USB Webcam Server.....	46	WAN Tab.....	29		
UserID.....	6	Warranty.....	80		
Username.....	6	Webcam			
V				Live View.....	47
Verizon Wireless.....	10, 64	Motion Detection.....	47		
Video.....	46	Streaming.....	47		
Video Streaming.....	47	Webcams.....	46		
		WiFi Password.....	33		
		WiFi Tab.....	32		